Original		Sustituto	
POWER	Power		Power
MUTE	Mute	MUTE	Mute
DTV/RADIO	DTV / Radio	SEARCH TV/R	TV/R
Senseye	Senseye	HOME SMART	Smart
BACKLIGHT	Backlight	APP MEDIA	Media
INFO	Info	DISPLAY INFO	Info
TV AUDIO	TV Audio	SOUND DUAL	Dual
ATV/DTV	ATV/DTV	SHIFT + SEARCH TV/R	Shift + TV/R
SLEEP	Sleep	PROG SLEEP	Sleep
SOUND	Sound	SHIFT + SOUND DUAL	Shift + Dual
PICTURE	Picture	SHIFT + PICTURE FORMAT	Shift + Format
FREEZE	Freeze	II	Pause
SUBTITLE	Subtitle	AD SUBT	Subt
WIDE	Wide	PICTURE FORMAT	Format
1	1	1	1
2	2	2	2
3	3	3	3

Original		Sustituto	
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
AVC	AVC	SHIFT + TIMER AV	Shift + AV
RETURN	Return	SHIFT + RETURN BACK	Shift + Back
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
GUIDE	Guide	GUIDE	Guide
LIST	List	DISC NAV LIST	List
PROG +	Prog +	CH +	Ch +
PROG -	Prog -	CH -	Ch -
BACK	Back	RETURN BACK	Back
FAVORITE	Favorite	FAV PRE-CH	Pre Ch

Original	Sustituto	Original	Sustituto
Up	Up	Yellow	Yellow
Left	Left	Blue	Blue
OK	Ok		
Right	Right		
Down	Down		
Input	AV		
Menu	Menu		
Hold	Stop		
Update	Exit		
Subcode	SHIFT + AD SUBT Shift + Subt		
Text / Mix	Text		
Index	SHIFT + DISPLAY INFO Shift + Info		
[≡..] / List	SHIFT + DISC NAV LIST Shift + List		
Size	Eject		
Reveal	D. Menu		
Red	Red		
Green	Green		