| Original | | Sustituto | |
|---|---|---|---|
| STANDBY | Standby | | Power |
| | Lock | HOME SMART | Smart |
| TIMER ON/OFF | Timer On/Off | PROG SLEEP | Sleep |
| AUDIO OUT | Audio Out | SOUND DUAL | Dual |
| SKIP SEARCH | Skip Search | PICTURE FORMAT | Format |
| ZERO BACK | Zero Back | RETURN BACK | Back |
| MENU | Menu | TOP MENU MENU | Menu |
| SET | Set | SETTINGS OPT | Options |
| SV/V+ /TIMER | SV/V+/Timer | FAV PRE-CH | Pre Ch |
| CLEAR | Clear | CLEAR EXIT | Exit |
| | UP | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |

| Original | | Sustituto | |
|---|---|---|---|
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| AM/PM | -/--/AM/PM | -/-- GUIDE | Guide |
| INPUT SELECT | Input Select | TIMER AV | AV |
| MODE OSD | Mode OSD | AD SUBT | Subt |
| DISPLAY | Display | DISPLAY INFO | Info |
| CHANNEL | Channel Up | + CH | Ch + |
| CHANNEL | Channel Down | CH − | Ch - |
| REW | << | << | << |
| PLAY/X2 | Play | PLAY MODE ▶ | Play |
| FF | >> | >> | >> |
| REC | Rec | REC MODE | Rec |

| Original | | Sustituto | | Original | Sustituto |
|---|---|---|---|---|---|
| STOP | Stop | ■ | Stop | | |
| PAUSE/STILL | Pause/Still | II | Pause | | |
| TAPE SPEED | Tape Speed | ECO 3D | 3D | | |
| SLOW | I >Slow | DISC NAV LIST | List | | |
| DPSS | < DPSS/ - | K< | I << | | |
| DPSS | DPSS >/ + | >>I | >>I | | |
| TV/VCR | TV/VCR | SEARCH TV/R | TV/R | | |
| OPERATE | Tv Operate | SHIFT + ⏻ | Shift + Power | | |
| INPUT SELECT | Input Select T | SHIFT + TIMER AV | Shift + AV | | |
| CH▲ | CH+ Tv | SHIFT + + CH | Shift + Ch + | | |
| CH▼ | CH- Tv | SHIFT + CH − | Shift + Ch - | | |
| VOL⊕ | Vol + Tv | + VOL | Vol + | | |
| VOL⊖ | Vol - Tv | VOL − | Vol - | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |