Original		Sustituto	
STANDBY/ON	Standby/On		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
P+	P+	CH +	Ch +
P-	P-	CH −	Ch -
STATUS/EXIT	Status/Exit	CLEAR EXIT	Exit
PLAY	Up		Up
STOP	Down		Down
FWD	Right		Right

Original		Sustituto	
REW	Left		Left
MENU	Menu	TOP MENU MENU	Menu
TV-VOL	Vol +	+ VOL	Vol +
TV-VOL	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute

Original		Sustituto	
STANDBY/ON	Standby/On		Power
REC	Rec	REC MODE	Rec
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
P+	P+	+ CH	Ch +
P-	P-	CH −	Ch -
STATUS/EXIT	Status/Exit	CLEAR EXIT	Exit
CLEAR	Clear	SHIFT + CLEAR EXIT	Shift + Exit
PLAY	Up		Up

Original		Sustituto	
STOP	Down		Down
FWD	Right		Right
REW	Left		Left
PLAY	Play	PLAY MODE	Play
STOP	Stop		Stop
FWD	>>		>>
REW	<<		<<
MENU	Menu	TOP MENU MENU	Menu
TV-VOL	Vol +	+ VOL	Vol +
TV-VOL	Vol -	VOL −	Vol -
STILL	>I <I / Still		Pause
MUTE	Mute	MUTE	Mute
INDEX	>I / Index	REPEAT TEXT	Text
SLOW	Slow	TIMER AV	AV
SYSTEM	System	APP MEDIA	Media
TURBO TIMER	Turbo Timer	SETTINGS OPT	Options
SV/V+	SV/N+	PICTURE FORMAT	Format

Original		Sustituto	
SMART PICTURE	Smart Picture	ECO 3D	3D
AUDIO	Audio	SOUND DUAL	Dual

Original	Sustituto