Original	Sustituto	Original	Sustituto
Standby / On	Power	▶▷ FWD / Right	Right
Mute	Mute / Dimmer	Clear	Exit / Cancel / Clear
▶ Play / Up	Play / Slow	Stop / Down	Down
▶| ◀ Still	Pause / Step / Freeze	TV Vol +	Vol +
■ Stop / Down	Stop / Hold	P+	CH+ / Page+
REC	Rec / Rec Mode	TV Vol -	Vol -
◁◀ REW / Left	<< / Tune-	P-	CH- / Page-
▶▷ FWD / Right	>> / Tune+	1	1
▶| / Index	>>| / Preset+	2	2
Audio	Audio / Lang I/II	3	3
Turbo Timer	Sleep / Timer	4	4
System	D. Menu / Top	5	5
Menu	Menu / Home	6	6
▶ Play / Up	Up	7	7
▶| / Index	Info / Angle	8	8
◁◀ REW / Left	Left	9	9
Menu	OK	0	0

Original	Sustituto	Original	Sustituto
Slow	SHIFT + SLOW Shift + Play /		
Status / Exit	SHIFT + CLEAR EXIT CANCEL Shift + Exit / Cancel / Clear		
TV Prog +	SHIFT + CH PAGE Shift + CH+ /		
TV Prog -	SHIFT + CH PAGE Shift + CH- /		