Original		Sustituto	
	Power		Power
	Open/Close	SURROUND	Eject / Surround
FUNCTION TV/SOURCE	Function	RDS AV INPUT	AV / Input / RDS
RDS DISPLAY 1	1/RDS Display	TV 1	1
2	2	DVD 2	2
TA 3	3/TA	CD-STB 3	3
PTY- 4	4/PTY-	VIDEO 4	4
PTY SEARCH 5	5/PTY Search	TAPE 5	5
PTY+ 6	6/PTY+	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
DISC MENU	Disc Menu	TOP MENU D.MENU	D.Menu / Top
0	0	HDMI-SAT 0	0
TITLE MENU POPUP	Title Menu PopUp	SHIFT +	TOP MENU D.MENU Shift + D.Menu / Top Menu
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+

Original		Sustituto	
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
VOL +	Vol +	VOL +	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
TUNING / CH	Tuning/CH-	CH PAGE −	CH- / Page-
TUNING / CH	Tuning/CH+	CH PAGE +	CH+ / Page+
VOL −	Vol -	VOL −	Vol -
TV SOUND	Tv Sound	TITLE SOUND	Sound / Title
S/W LEVEL	S/W Level	FORMAT PICTURE	Picture / Format
HOME	Home	HOME MENU	Menu / Home
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
INFO i	Info	ANGLE INFO	Info / Angle

Original	Sustituto	Original	Sustituto
Left	Left		
Enter	OK		
Right	Right		
Return	Back / Return		
Down	Down		
Exit	Exit / Cancel / Clear		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow/Tuner	Yellow / YouTube / Repeat		
Blue/Mo/St	Blue / Prime Video / Random		
Smart Hub	Smart / List		
Search	Shift + Red / Netflix /		
Sound Effect	Shift + Sound / Title		
3D/Sound	Audio / Lang I/II		

Original		Sustituto	
	Power		Power
FUNCTION TV/SOURCE	Function	RDS AV INPUT	AV / Input / RDS
RDS DISPLAY 1	1/ RDS Display	TV 1	1
2	2	DVD 2	2
TA 3	3/ TA	CD - STB 3	3
PTY- 4	4/ PTY-	VIDEO 4	4
PTY SEARCH 5	5/ PTY Search	TAPE 5	5
PTY+ 6	6/ PTY+	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
	I <<	PRESET-	I << / Preset-
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Stop	HOLD	Stop / Hold

Original		Sustituto	
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze
VOL	Vol +	VOL	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
TUNING / CH	Tuning/ CH-	CH PAGE	CH- / Page-
TUNING / CH	Tuning/ CH+	CH PAGE	CH+ / Page+
VOL	Vol -	VOL	Vol -
	Tv Sound	TITLE SOUND	Sound / Title
HOME	Home	HOME MENU	Menu / Home
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
INFO	Info	ANGLE INFO	Info / Angle
	Left		Left
	Enter	OK	OK
	Right		Right
RETURN	Return	RETURN BACK	Back / Return

Original		Sustituto		Original	Sustituto
	Down		Down		
	Exit		Exit / Cancel / Clear		
	Red		Red / Netflix / Search		
	Green		Green / APP / Repeat		
	Yellow/Tuner		Yellow / YouTube / Repeat		
	Blue/Mo/St		Blue / Prime Video / Random		
	Smart Hub		Smart / List		
	Search		Shift + Red / Netflix /		