Original		Sustituto	
	Source	RDS AV INPUT	AV / Input / RDS
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
PRE PR	PRE PR	RETURN BACK	Back / Return
DTV /ATV	DTV/ ATV	OPT-TOOLS SETUP	Setup / OPT /
PR LIST	PR List	LIST SMART	Smart / List
ECO	ECO	PC FAV MARKER	Fav / Marker / PC

Original		Sustituto	
	[i+]	ANGLE INFO	Info / Angle
	Vol +	VOL	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
P	PR+	CH PAGE	CH+ / Page+
	Vol -	VOL	Vol -
	[<>]	FORMAT PICTURE	Picture / Format
P	PR-	CH PAGE	CH- / Page-
DUAL	Dual	LANG I/II AUDIO	Audio / Lang I/II
AUDIO ADJ	AJD Audio	TITLE SOUND	Sound / Title
VIDEO ADJ	ADJ Video	TOP MENU D.MENU	D. Menu / Top
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
MENU	Menu	HOME MENU	Menu / Home
	Down		Down

Original		Sustituto		Original	Sustituto
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
TELETEXT	Teletext	GOTO TEXT	Text / Goto		
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
SIZE	Size	SIZE ZOOM	Zoom / Size		
SUBPAGE	Subpage	SURROUND	Eject / Surround		
INDEX	Index	MEDIA DISPLAY	Display / Media		
HOLD	Hold	SHIFT + HOLD	Shift + Stop /		
REVEAL	Reveal	PROGRAM TV/ RADIO	TV/ Radio /		
FREEZE	Freeze	STEP-FREEZE	Pause / Step / Freeze		
	I<<	PRESET-	I<< / Preset-		
	Stop	HOLD	Stop / Hold		
	Play/ Pause	SLOW	Play / Slow		
	>>I	PRESET+	>>I / Preset+		