Original		Sustituto	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
Freeze	Freeze	SHIFT + STEP - FREEZE	Shift + Pause / Step /
0	0	HDMI - SAT 0	0
Aspect Ratio	Aspect Ratio	TOP MENU D.MENU	D. Menu / Top
Guide	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
?	?	SHIFT + ANGLE INFO	Shift + Info / Angle
TXT	TXT	GOTO TEXT	Text / Goto

Original		Sustituto	
OPT	OPT	OPT-TOOLS SETUP	Setup / OPT /
	Back	RETURN BACK	Back / Return
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
Menu	Menu	HOME MENU	Menu / Home
Exit	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
Info	Info	ANGLE INFO	Info / Angle
Vol	Vol +	+ VOL	Vol +
	↑ Page+	SHIFT +	Shift + Up
Ch	CH+	+ CH PAGE	CH+ / Page+
Vol	Vol -	VOL −	Vol -
	↓ Page-	SHIFT +	Shift + Down
Ch	CH-	CH PAGE −	CH- / Page-
	Red	NETFLIX SEARCH	Red / Netflix / Search

Original		Sustituto		Original	Sustituto
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
TV/R	TV/R	PROGRAM TV/ RADIO	TV/Radio /		
SUB	SUB	EQ SUBTITLE	Subtitle / EQ		
LANG	LANG	LANG I/II AUDIO	Audio / Lang I/II		
◷	◷	TIMER SLEEP	Sleep / Timer		
●	Rec	REC MODE ●	Rec / Rec Mode		
▶	Play	SLOW ▶	Play / Slow		
⏸	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze		
■	Stop	HOLD ■	Stop / Hold		
◀◀	<<	TUNE- ◀◀	<< / Tune-		
⏮	I<	PRESET- ⏮	I<< / Preset-		
⏭	>I	PRESET+ ⏭	>>I / Preset+		
▶▶	>>	TUNE+ ▶▶	>> / Tune+		