Original		Sustituto	
	Power		Power
	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0 AV	0 / AV	0	0
0 AV	0 / AV	TIMER AV	AV
ZOOM	Red / Zoom	A	Red
ZOOM	Red / Zoom	ZOOM	Eject
	Green / Audio	B	Green
	Green / Audio	SOUND DUAL	Dual

Original		Sustituto	
	Yellow	C	Yellow
	Blue	D	Blue
	i	DISPLAY INFO	Info
	Text	REPEAT TEXT	Text
P^	Up / P+		Up
P^	Up / P+	+ CH	Ch +
P^	Down / P-		Down
P^	Down / P-	CH –	Ch -
	Right / Vol +	+ VOL	Vol +
	Right / Vol +		Right
	Left / Vol -	VOL –	Vol -
	Left / Vol -		Left
MENU OK	Menu / OK	TOP MENU MENU	Menu
MENU OK	Menu / OK	OK	Ok
	[ ]		Stop
F.T/L	F.T/L	HOME SMART	Smart
	[?]	APP MEDIA	Media

Original	Sustituto	Original	Sustituto
[⇕]	SHIFT + ZOOM Shift + Eject		
[⏲]	PROG SLEEP Sleep		
>	FAV PRE-CH Pre Ch		
[X]	CLEAR EXIT Exit		
[≡i]	PICTURE FORMAT Format		

Original		Sustituto	
	Power		Power
	Menu		Menu
	OK		Ok
	Up		Up
	Down		Down
	Ri ght		Ri ght
	Lef t		Lef t
	<<		<<
	Pl ay		Pl ay
	>>		>>
	St op		St op
	Rec		Rec
	↑		Ch +
	↓		Ch -

Original	Sustituto

Original		Sustituto	
	Power		Power
	<<		<<
	Pl ay		Pl ay
	>>		>>
	Rec		Rec
	St op		St op
	Up		Up
	Down		Down

Original	Sustituto