Mandis shop

Sony RM-AMU197

Original	Sustituto	Original	Sustituto
Display	Display / Media	>>I / Preset +	>>I / Preset +
Power	Power	<<I / Tuning-	<< / Tune-
Function-	Shift + Down	Stop	Stop / Hold
Function+	Shift + Up	>>I / Tuning+	>> / Tune+
Sound	Sound / Title	Vol +	Vol +
Menu	Menu / Home	Vol -	Vol -
Timer	Sleep / Timer		
Up	Up		
Folder-	CH- / Page-		
OK	OK		
Folder+	CH+ / Page+		
Down	Down		
Return	Back / Return		
Clear	Exit / Cancel / Clear		
I <<I / Preset-	I << / Preset-		
Play	Play / Slow		
Pause	Pause / Step / Freeze		

https://mandis.es/es/Sony/10137-780-mando-sustituto-para-Sony-RM-AMU197-192751.html