Original		Sustituto	
	Power		Power
	3D		3D
	Source		AV
	Setup/ Media		Media
	Setup/ Media		Options
	Mode		Smart
	Hide		Exit
	Zoom		Eject
	Ratio		Format
	Freeze		Pause
	Up/ Keystone+		Up
	Down / Keystone-		Down
	Left		Left
	Menu		Menu
	Right		Right
	1/ <</ I <		1
	1/ <</ I <		<<

Original		Sustituto	
	1/ <</ I <		I <<
	2/ Play/ Pause/ Ent		2
	2/ Play/ Pause/ Ent		Play
	2/ Play/ Pause/ Ent		Ok
	3/ Stop/ Back		Back
	3/ Stop/ Back		3
	3/ Stop/ Back		Stop
	PgUp/ >>/ I >		Ch +
	PgUp/ >>/ >I		>>
	PgUp/ >>/ >I		>>I
	4/ VGA		Red
	4/ VGA		4
	5/ Component		5
	5/ Component		Green
	6/ Video		6
	6/ Video		Yellow
	PgDn/ S-Video		Blue

Original	Sustituto	Original	Sustituto
PgDn/S-Video	Ch -		
7/SD/USB A	7		
7/SD/USB A	Shift + Red		
8/HDMI/DVI	8		
8/HDMI/DVI	Shift + Green		
9/LAN/Wifi	9		
9/LAN/Wifi	Shift + Yellow		
0/USB B	0		
0/USB B	Shift + Blue		