Mandis shop

LG AKB74935621

Original		Sustituto	
	Power		Power
F	F	TOP MENU MENU	Menu
OPTICAL	Optical	SETTINGS OPT	Options
STANDARD	Standard	HOME SMART	Smart
BASS BLAST	Bass Blast	APP MEDIA	Media
VOL +	Vol +	+ VOL	Vol +
VOL -	Vol -	VOL -	Vol -
	Mute	MUTE	Mute
	I<<		I<<
	Play	PLAY MODE	Play
	Pause		Pause
	>>I		>>I
DRC ON	DRC On	+ CH	Ch +
DRC OFF	DRC Off	CH -	Ch -
WOOFER LEVEL +	Woofer Level +		Up
WOOFER LEVEL -	Woofer Level -		Down
AUTO POWER ON	Auto Power On		Right

Original		Sustituto	
AUTO POWER OFF	Auto Power Off		Left