Original		Sustituto	
	Power		Power
	Mute	MUTE	Mute
	Set	APP MEDIA	Media
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	Home	HOME SMART	Smart
	Pause		Pause
	Play	PLAY MODE	Play
	Back	RETURN BACK	Back
	Menu	TOP MENU MENU	Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK	OK	Ok

Original		Sustituto	
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	On Page	SEARCH TV/R	TV/R
	Next Page	SETTINGS OPT	Options
	CH+	+ CH	Ch +
	CH-	CH −	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
删除	Delete	GUIDE	Guide

Original		Sustituto	
# 输入法	I nput	TIMER AV	AV

Original	Sustituto