Original		Sustituto	
	Power		Power
OPEN/CLOSE	Open/Close	ZOOM	Eject
FUNCTION	Function	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep
MUSIC ID	Music ID	APP MEDIA	Media
REC	Rec	REC MODE	Rec
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CLEAR	Clear	CLEAR EXIT	Exit

Original		Sustituto	
REPEAT	Repeat	REPEAT TEXT	Text
SKIP	I<< Skip		I<<
SCAN	<< Scan		<<
SCAN	Scan >>		>>
SKIP	Skip >>I		>>I
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
SPEAKER LEVEL	Speaker Level	AD SUBT	Subt
SOUND EFFECT	Sound Effect	SOUND DUAL	Dual
OPTICAL	Optical	SETTINGS OPT	Options
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute
HOME	Home	HOME SMART	Smart
INFO/MENU	Info/Menu	TOP MENU MENU	Menu
PRESET	Up Preset		Up

Original		Sustituto	
	Down Preset		Down
	Right/Tuning+		Right
	Left/Tuning-		Left
ENTER	Enter	OK	Ok
BACK	Back	RETURN BACK	Back
TITLE/POP UP	Title/Pop Up	DISPLAY INFO	Info
DISC MENU	Disc Menu	E-MANUAL D.MENU	D. Menu
RDS R	Red/RDS	A	Red
PTY G	Green/PTY	B	Green
PTY SEARCH Y	Yellow/PTY Searc	C	Yellow
MONO/STEREO B	Blue/Mono/Stereo	D	Blue
MARKER	Marker	ECO 3D	3D
SEARCH	Search	SEARCH TV/R	TV/R
TV	Power Tv	SHIFT +	Shift + Power
AV/INPUT	AV/Input Tv	SHIFT + TIMER AV	Shift + AV
+ VOL	Vol + Tv	SHIFT + + VOL	Shift + Vol +
VOL −	Vol - Tv	SHIFT + VOL −	Shift + Vol -

Original		Sustituto	
PR/CH	PR/CH+ Tv	+ CH	Ch +
PR/CH	PR/CH- Tv	CH −	Ch -