Original		Sustituto	
	Power		Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
PLAY	Timer Play	SHIFT + SLOW ▶	Shift + Play /
REC	Timer Rec	REC MODE	Rec / Rec Mode
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
≥10	≥10	-/-- GUIDE EPG	Guide / EPG / -/--
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Sustituto	
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
DISPLAY	Display	MEDIA DISPLAY	Display / Media
AUTO/MONO	Auto/Mono	LIST SMART	Smart / List
CD	CD	SHIFT + CD-STB 3	Shift + 3
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
EXT	EXT	RDS AV INPUT	AV / Input / RDS
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
■	Stop	HOLD ■	Stop / Hold
◀/II	Pause	STEP-FREEZE II	Pause / Step / Freeze
▶	Play	SLOW ▶	Play / Slow
TUNE ∧	Tune+	SHIFT + TUNE+ ▶▶	Shift + >> /
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
◀◀/◀◀	I <</ <<	TUNE- ◀◀	<< / Tune-
▶▶/▶▶I	>>/ >>I	TUNE+ ▶▶	>> / Tune+
TUNE ∨	Tune-	SHIFT + TUNE- ◀◀	Shift + << /
VOLUME	Volume-	VOL −	Vol -

Original	Sustituto	Original	Sustituto
Volume+	Vol +		