Original		Sustituto	
	Power		Power
	Energy Saving	SHIFT + ECO 3D	Shift + 3D
	AV Mode	SHIFT + TIMER AV	Shift + AV
	Input	TIMER AV	AV
	TV/RAD	SEARCH TV/R	TV/R
	1	1	1
	2	2	2
	3	3	3
	4	4	4
	5	5	5
	6	6	6
	7	7	7
	8	8	8
	9	9	9
	0	0	0
	List	DISC NAV LIST	List
	Q.View	E-MANUAL D.MENU	D. Menu

Original		Sustituto	
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Mark / FAV / Char/Num	FAV PRE-CH	Pre Ch
	3D	ECO 3D	3D
	Mute	MUTE	Mute
	P+/Page Up	+ CH	Ch +
	P-/Page Down	CH −	Ch -
	Smart TV	SHIFT + HOME SMART	Shift + Smart
	Smart TV Home	HOME SMART	Smart
	Q.Menu/3D	TOP MENU MENU	Menu
	Up		Up
	Left		Left
	OK	OK	Ok
	Right		Right
	Down		Down
	Back	RETURN BACK	Back
	Guide	-/-- GUIDE	Guide

Original		Sustituto	
EXIT	Exit	CLEAR EXIT	Exit
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
TEXT	Text	REPEAT TEXT	Text
T.OPT	T. Opt	SETTINGS OPT	Options
SUBTITLE	Subtitle	AD SUBT	Subt
■	Stop	■	Stop
▶	Play	PLAY MODE ▶	Play
II	Pause	II	Pause
◀◀	<<	<<	<<
▶▶	>>	>>	>>
RATIO	[ ] / Ratio	PICTURE FORMAT	Format
INFO	Info	DISPLAY INFO	Info
AD	AD	SHIFT + AD SUBT	Shift + Subt
APP/*	APP/*	APP MEDIA	Media

Original	Sustituto