Mandis shop

GYM001

Original		Sustituto		Original	Sustituto
	Power		Power		
START/STOP	Start/Stop	PLAY MODE	Play		
+ SPEED	Speed+		Up		
- SPEED	Speed-		Down		
TIME-	Time-		Left		
TIME+	Time+		Right		
PROGRAM	Program	HOME SMART	Smart		
MANUAL	Manual	APP MEDIA	Media		

https://mandisremotes.com/es/Gym-Form/1063091-92940-mando-de-sustitucion-para-Gym-Form-GYM001.html