Original		Sustituto	
POWER ON	Power On		Power
STANDBY	Standby	SHIFT +	Shift + Power
DVI	DVI	SHIFT + 1	Shift + 1
DISPLAY PORT	Display Port	SHIFT + 2	Shift + 2
VGA	VGA	SHIFT + 3	Shift + 3
RGB/HV	RGB / HV	SHIFT + 4	Shift + 4
HDMI	HDMI	SHIFT + 5	Shift + 5
DVD/HD	DVD/HD	SHIFT + 6	Shift + 6
VIDEO	VIDEO	SHIFT + 7	Shift + 7
S-VIDEO	S-Video	SHIFT + 8	Shift + 8
PICTURE MODE	Picture Mode	SHIFT + PICTURE FORMAT	Shift + Format
ASPECT	Aspect	PICTURE FORMAT	Format
SOUND	Sound	SOUND DUAL	Dual
OPTION	Option	SETTINGS OPT	Options
1	1	1	1
2	2	2	2
3	3	3	3

Original		Sustituto	
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-	--	SHIFT + GUIDE	Shift + Guide
ENT	ENT	FAV PRE-CH	Pre Ch
DISPLAY	Display	DISPLAY INFO	Info
MENU	Menu	TOP MENU MENU	Menu
	Up		Up
	Left / -		Left
SET	SET	OK	Ok
+	Right / +		Right
	Down		Down
AUTO SET UP	Auto Set Up	HOME SMART	Smart

Original		Sustituto	
EXIT	Exit	CLEAR EXIT	Exit
VOL +	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -
GUIDE	Guide	-/-- GUIDE	Guide
MUTE	Mute	MUTE	Mute
CH +	CH+	+ CH	Ch +
–	CH-	CH –	Ch -
STILL ON/OFF	Still On/Off	■	Stop
CAPTURE	Still Capture	REC MODE ●	Rec
[≡]	[≡]	REPEAT TEXT	Text
PIP ON/OFF	PIP On/OFF	A	Red
INPUT	PIP Input	B	Green
CHANGE	PIP Change	C	Yellow
MTS	MTS	APP MEDIA	Media
AUDIO INPUT	Audio Input	TIMER AV	AV

Original	Sustituto