Original		Sustituto	
	Power		Power
C	C	FAV PRE-CH	Pre Ch
MULTI WINDOW	Multi Window	HOME SMART	Smart
ASPECT	Aspect	PICTURE FORMAT	Format
SRS	SRS	SOUND DUAL	Dual
	SD	APP MEDIA	Media
	Mute	MUTE	Mute
TV/AV	TV/AV	TIMER AV	AV
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
	Red	A	Red
	Green	B	Green

Original		Sustituto	
	Yellow	C	Yellow
	Blue	D	Blue
TEXT	Text	REPEAT TEXT	Text
F.P.	F. P.	ECO 3D	3D
INDEX	Index	SEARCH TV/R	TV/R
HOLD	Hold	SHIFT +	Shift + Stop
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0 VCR	0 / VCR	0	0
N	N	SETTINGS OPT	Options

Original		Sustituto		Original		Sustituto	
i	i	DISPLAY INFO	Info	DIRECT TV REC	Direct TV Rec	SHIFT + REC MODE	Shift + Rec
∧	CH+	+ CH	Ch +				
∨	CH-	CH −	Ch -				
+	Vol +	+ VOL	Vol +				
−	Vol -	VOL −	Vol -				
PROGRAMME ∧	Programme+	SHIFT +	+ CH Shift + Ch +				
PROGR ∨	Programme-	SHIFT +	CH − Shift + Ch -				
⏮	<< / I <<	«	<<				
⏮	<< / I <<	⏮	I <<				
⏭	>> / >>I	»	>>				
⏭	>> / >>I	⏭	>>I				
■	Stop	■	Stop				
II/I▸	Pause / Step	II	Pause				
▶	Play	PLAY MODE ▶	Play				
⏻	Power (DVD)	SHIFT +	⏻ Shift + Power				
SD REC	SD Rec	SHIFT +	APP MEDIA Shift + Media				
REC	Rec	REC MODE	Rec				