Mandis shop

RM-SD50

Original	Sustituto	Original	Sustituto
Power	Power	Disc Skip	Media
Sleep	Sleep	Vol +	Vol +
Loop	Smart	Vol -	Vol -
Play CD	Play	Up	Up
Pause CD	Pause	Down	Down
Stop CD	Stop	Right	Right
Play	Yellow	Left	Left
I << Tuner/Band	I <<	On/Off	Ok
>>I Tuner/Band	>>I		
Play Deck A	Red		
<< Deck A	<<		
>> Deck A	>>		
Play Deck B	Green		
Check	Pre Ch		
Edit	Blue		
Function	Menu		
Clear	Exit		

https://mandis.com/es/Sony/10360-987-mando-sustitucion-para-Sony-RM-SD50.html