| Original | | Sustituto | |
|---|---|---|---|
| ON | Power On | Power | |
| OFF | Power Off | SHIFT + Power | Shift + Power |
| ZONE DEVICE ON | Zone Device On | HOME SMART | Smart |
| ZONE OFF | Zone Device Off | SHIFT + HOME SMART | Shift + Smart |
| NET/USB | Net/USB | SHIFT + 1 | Shift + 1 |
| PLAY iPod | iPod | SHIFT + 2 | Shift + 2 |
| DVD | DVD | SHIFT + 3 | Shift + 3 |
| BD | BD | SHIFT + 4 | Shift + 4 |
| TUNER /DTU | Tuner/DTU | SHIFT + 5 | Shift + 5 |
| DOCK | Dock | SHIFT + 6 | Shift + 6 |
| SAT TU | SAT TU | SHIFT + 7 | Shift + 7 |
| SAT/CBL | SAT/CBL | SHIFT + 8 | Shift + 8 |
| GAME | Game | SHIFT + 9 | Shift + 9 |
| | V. AUX | SHIFT + -/-- GUIDE | Shift + Guide |
| PHONO | Phono | SHIFT + 0 | Shift + 0 |
| CD | CD | SHIFT + FAV PRE-CH | Shift + Pre Ch |
| DVR | DVR | D | Blue |

| Original | | Sustituto | |
|---|---|---|---|
| TV | TV | SHIFT + APP MEDIA | Shift + Media |
| MONITOR SELECT | Monitor Select | APP MEDIA | Media |
| (BD) 1 | Quick Select 1 | A | Red |
| (SAT/CBL) 2 | Quick Select 2 (SAT/CBL) | B | Green |
| (DOCK) 3 | Quick Select 3 (Dock) | C | Yellow |
| + CH | CH+ | + CH | Ch + |
| − | CH- | CH − | Ch - |
| ▲ VOL | Vol + | + VOL | Vol + |
| ▼ | Vol - | VOL − | Vol - |
| MUTE | Mute | MUTE | Mute |
| SOURCE SELECT | Source Select | TIMER AV | AV |
| MENU | Menu | TOP MENU MENU | Menu |
| TOP MENU CH LEVEL | CH Level / Top | DISPLAY INFO | Info |
| SETUP SEARCH | Search/Setup | SETTINGS OPT | Options |
| RETURN | Return | RETURN BACK | Back |
| ▲ | Up | ▲ | Up |
| ▼ | Down | ▼ | Down |

| Original | | Sustituto | |
|---|---|---|---|
| | Right | | Right |
| | Left | | Left |
| ENTER | Enter | OK | Ok |
| BAND | <</ Band | | << |
| | Play | PLAY MODE | Play |
| MODE | >>/ Mode | | >> |
| TUNING | I <</ Tuning- | | I << |
| | Pause | | Pause |
| | Stop | | Stop |
| TUNING | >>I / Tuning+ | | >>I |
| MULTEQ | Multeq | AD SUBT | Subt |
| DYN EQ/VOL | Dyn EQ/ Vol | REPEAT TEXT | Text |
| A-DSX | A-DSX | SEARCH TV/R | TV/ R |
| RESTORER | Restorer | CLEAR EXIT | Exit |
| STANDARD | Standard | SOUND DUAL | Dual |
| D/ST | D/ ST | PICTURE FORMAT | Format |
| SIMULATION | Simulation | ECO 3D | 3D |

| Original | | Sustituto | |
|---|---|---|---|
| PURE | Pure | FAV PRE-CH | Pre Ch |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 DEF | 3 | 3 | 3 |
| 4 GHI | 4 | 4 | 4 |
| 5 JKL | 5 | 5 | 5 |
| 6 MNO | 6 | 6 | 6 |
| 7 PQRS | 7 | 7 | 7 |
| 8 TUV | 8 | 8 | 8 |
| 9 WXYZ | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| | +10/ Memory | -/-- GUIDE | Guide |
| | Shift/ Link Men | E-MANUAL D.MENU | D. Menu |
| POWER TV | Power Tv | SHIFT + SEARCH TV/R | Shift + TV/ R |
| INPUT | Input Tv | SHIFT + TIMER AV | Shift + AV |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| | Party | DISC NAV LIST | List |

| Original | | Sustituto | |
|---|---|---|---|
| ON | Power On | | Power |
| OFF | Power Off | SHIFT + | Shift + Power |
| ZONE DEVICE ON | Zone Device On | HOME SMART | Smart |
| ZONE DEVICE OFF | Zone Device Off | SHIFT + HOME SMART | Shift + Smart |
| NET/USB | Net/USB | SHIFT + 1 | Shift + 1 |
| PLAY iPod | iPod | SHIFT + 2 | Shift + 2 |
| DVD | DVD | SHIFT + 3 | Shift + 3 |
| BD | BD | SHIFT + 4 | Shift + 4 |
| TUNER /DTU | Tuner/DTU | SHIFT + 5 | Shift + 5 |
| DOCK | Dock | SHIFT + 6 | Shift + 6 |
| SAT TU | SAT TU | SHIFT + 7 | Shift + 7 |
| SAT/CBL | SAT/CBL | SHIFT + 8 | Shift + 8 |
| GAME | Game | SHIFT + 9 | Shift + 9 |
| V.AUX | V. AUX | SHIFT + GUIDE | Shift + Guide |
| PHONO | Phono | SHIFT + 0 | Shift + 0 |
| CD | CD | FAV PRE-CH | Pre Ch |
| DVR | DVR | D | Blue |

| Original | | Sustituto | |
|---|---|---|---|
| TV | TV | APP MEDIA | Media |
| (BD) 1 | Quick Select 1 | A | Red |
| (SAT/CBL) 2 | Quick Select 2 (SAT/CBL) | B | Green |
| (DOCK) 3 | Quick Select 3 (Dock) | C | Yellow |
| + CH | CH+ | + CH | Ch + |
| − | CH- | CH − | Ch - |
| VOL | Vol + | + VOL | Vol + |
| VOL | Vol - | VOL − | Vol - |
| MUTE | Mute | MUTE | Mute |
| MENU | Menu | TOP MENU MENU | Menu |
| TOP MENU CH LEVEL | CH Level / Top | DISPLAY INFO | Info |
| SETUP SEARCH | Search/Setup | SETTINGS OPT | Options |
| RETURN | Return | RETURN BACK | Back |
| ▲ | Up | ▲ | Up |
| ▼ | Down | ▼ | Down |
| ▶ | Right | ▶ | Right |
| ◀ | Left | ◀ | Left |

| Original | | Sustituto | |
|---|---|---|---|
| ENTER | Enter | OK | Ok |
| BAND | <</Band | << | << |
| ► | Play | PLAY MODE ► | Play |
| MODE | >>/Mode | >> | >> |
| TUNING | I<</Tuning- | I<< | I<< |
| ❚❚ | Pause | ❚❚ | Pause |
| ■ | Stop | ■ | Stop |
| TUNING | >>I/Tuning+ | >>I | >>I |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 DEF | 3 | 3 | 3 |
| 4 GHI | 4 | 4 | 4 |
| 5 JKL | 5 | 5 | 5 |
| 6 MNO | 6 | 6 | 6 |
| 7 PQRS | 7 | 7 | 7 |
| 8 TUV | 8 | 8 | 8 |
| 9 WXYZ | 9 | 9 | 9 |

| Original | | Sustituto | |
|---|---|---|---|
| 0 | 0 | 0 | 0 |
| +10 MEMORY | +10/Memory | -/-- GUIDE | Guide |
| SHIFT LINK MENU | Shift/Link Men | E-MANUAL D.MENU | D. Menu |
| POWER TV | Power Tv | SEARCH TV/R | TV/R |
| INPUT | Input TV | TIMER AV | AV |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| PARTY | Party | DISC NAV LIST | List |

| Original | | Sustituto | |
|---|---|---|---|
| ON | Power On | | Power |
| OFF | Power Off | SHIFT + | Shift + Power |
| ZONE ON | Zone Device On | HOME SMART | Smart |
| ZONE OFF | Zone Device Off | SHIFT + HOME SMART | Shift + Smart |
| NET/USB | Net/USB | SHIFT + 1 | Shift + 1 |
| PLAY iPod | iPod | SHIFT + 2 | Shift + 2 |
| DVD | DVD | SHIFT + 3 | Shift + 3 |
| BD | BD | SHIFT + 4 | Shift + 4 |
| TUNER /DTU | Tuner/DTU | SHIFT + 5 | Shift + 5 |
| DOCK | Dock | SHIFT + 6 | Shift + 6 |
| SAT TU | SAT TU | SHIFT + 7 | Shift + 7 |
| SAT/CBL | SAT/CBL | SHIFT + 8 | Shift + 8 |
| GAME | Game | SHIFT + 9 | Shift + 9 |
| V.AUX | V. AUX | SHIFT + GUIDE | Shift + Guide |
| PHONO | Phono | SHIFT + 0 | Shift + 0 |
| CD | CD | FAV PRE-CH | Pre Ch |
| DVR | DVR | D | Blue |

| Original | | Sustituto | |
|---|---|---|---|
| TV | TV | APP MEDIA | Media |
| (BD) 1 | Quick Select 1 | A | Red |
| (SAT/CBL) 2 | Quick Select 2 (SAT/CBL) | B | Green |
| (DOCK) 3 | Quick Select 3 (Dock) | C | Yellow |
| + CH | CH+ | + CH | Ch + |
| − | CH- | CH − | Ch - |
| VOL ▲ | Vol + | + VOL | Vol + |
| VOL ▼ | Vol - | VOL − | Vol - |
| MUTE | Mute | MUTE | Mute |
| MENU | Menu | TOP MENU MENU | Menu |
| TOP MENU CH LEVEL | CH Level/Top | DISPLAY INFO | Info |
| SETUP SEARCH | Search/Setup | SETTINGS OPT | Options |
| RETURN | Return | RETURN BACK | Back |
| ▲ | Up | ▲ | Up |
| ▼ | Down | ▼ | Down |
| ▶ | Right | ▶ | Right |
| ◀ | Left | ◀ | Left |

| Original | | Sustituto | |
|---|---|---|---|
| ENTER | Enter | OK | Ok |
| BAND | <</Band | | << |
| | Play | PLAY MODE | Play |
| MODE | >>/Mode | | >> |
| TUNING | I<</Tuning- | | I<< |
| | Pause | | Pause |
| | Stop | | Stop |
| TUNING | >>I/Tuning+ | | >>I |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 DEF | 3 | 3 | 3 |
| 4 GHI | 4 | 4 | 4 |
| 5 JKL | 5 | 5 | 5 |
| 6 MNO | 6 | 6 | 6 |
| 7 PQRS | 7 | 7 | 7 |
| 8 TUV | 8 | 8 | 8 |
| 9 WXYZ | 9 | 9 | 9 |

| Original | | Sustituto | |
|---|---|---|---|
| 0 | 0 | 0 | 0 |
| +10 MEMORY | +10/Memory | -/-- GUIDE | Guide |
| SHIFT LINK MENU | Shift/Link Men | E-MANUAL D.MENU | D. Menu |
| POWER TV | Power Tv | SEARCH TV/R | TV/R |
| INPUT | Input Tv | TIMER AV | AV |
| PARTY | Party | DISC NAV LIST | List |
| SLEEP | Sleep | PROG SLEEP | Sleep |

| Original | | Sustituto | |
|---|---|---|---|
| ON | Power On | | Power |
| OFF | Power Off | SHIFT + | Shift + Power |
| ZONE DEVICE ON | Zone Device On | HOME SMART | Smart |
| ZONE DEVICE OFF | Zone Device Off | SHIFT + HOME SMART | Shift + Smart |
| NET/USB | NET/USB | SHIFT + 1 | Shift + 1 |
| PLAY iPod | iPod | SHIFT + 2 | Shift + 2 |
| DVD | DVD | SHIFT + 3 | Shift + 3 |
| BD | BD | SHIFT + 4 | Shift + 4 |
| TUNER /DTU | Tuner/DTU | SHIFT + 5 | Shift + 5 |
| DOCK | Dock | SHIFT + 6 | Shift + 6 |
| SAT TU | SAT TU | SHIFT + 7 | Shift + 7 |
| SAT/CBL | SAT/CBL | SHIFT + 8 | Shift + 8 |
| GAME | Game | SHIFT + 9 | Shift + 9 |
| V.AUX | V. AUX | SHIFT + GUIDE | Shift + Guide |
| PHONO | Phono | SHIFT + 0 | Shift + 0 |
| CD | CD | FAV PRE-CH | Pre Ch |
| DVR | DVR | D | Blue |

| Original | | Sustituto | |
|---|---|---|---|
| TV | TV | APP MEDIA | Media |
| (BD) 1 | Quick Select 1 | A | Red |
| (SAT/CBL) 2 | Quick Select 2 (SAT/CBL) | B | Green |
| (DOCK) 3 | Quick Select 3 (Dock) | C | Yellow |
| + CH | CH+ | + CH | Ch + |
| − | CH- | CH − | Ch - |
| ▲ VOL | Vol + | + VOL | Vol + |
| ▼ | Vol - | VOL − | Vol - |
| MUTE | Mute | MUTE | Mute |
| SETUP SEARCH | Search/Setup | SETTINGS OPT | Options |
| BAND ◄◄ | <</Band | ◄◄ | << |
| ► | Play | PLAY MODE ► | Play |
| MODE ►► | >>/Mode | ►► | >> |
| TUNING ▼ I◄◄ | I<</Tuning- | I◄◄ | I<< |
| ▮▮ | Pause | ▮▮ | Pause |
| ■ | Stop | ■ | Stop |
| TUNING ▲ ►►I | >>I/Tuning+ | ►►I | >>I |

| Original | | Sustituto | |
|---|---|---|---|
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| +10 MEMORY | +10/Memory | GUIDE | Guide |
| POWER TV | Power Tv | SEARCH TV/R | TV/R |
| SHIFT LINK MENU | Shift/Link Men | E-MANUAL D.MENU | D. Menu |
| INPUT | Input Tv | TIMER AV | AV |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| PARTY | Party | DISC NAV LIST | List |

| Original | Sustituto |
|---|---|
| | |
| | |
| | |