Mandis shop

Optoma 200150

Original		Sustituto	
Power	POWER	Power	Power
Switch	Switch Mouse	DISPLAY INFO	Info
	[/]	PROG SLEEP	Sleep
Freeze	FREEZE		Pause
	MUTE	MUTE	Mute
L	L	CLEAR EXIT	Exit
R	R	RETURN BACK	Back
	UP		Up
	LEFT		Left
Enter	ENTER	OK	Ok
	RIGHT		Right
	DOWN		Down
Page-	PAGE -	CH –	Ch -
Page+	PAGE +	+ CH	Ch +
Keys –	KEYSTONE -	APP MEDIA	Media
stone +	KEYSTONE +	HOME SMART	Smart
Volu –	VOLUME-	VOL –	Vol -

Original		Sustituto	
ume +	VOLUME+	+ VOL	Vol +
1	1 / ASPECT	1	1
1	1 / ASPECT	PICTURE FORMAT	Format
2 Menu	2 / MENU	TOP MENU MENU	Menu
2 Menu	2 / MENU	2	2
3 3D	3 / 3D	3	3
3 3D	3 / 3D	ECO 3D	3D
4 HDMI	4 / HDMI	4	4
5 VGA	5 / VGA	5	5
6 Video	6 / VIDEO	6	6
7 User1	7 / USER1	7	7
8 User2	8 / USER2	8	8
9 User3	9 / USER3	9	9
0	0 / BRIGHTNESS	0	0
Source	SOURCE	TIMER AV	AV
Resync	RE-SYNC	E-MANUAL D.MENU	D. Menu

https://mandis.es/es/Optoma/1031-376-mando-sustituto-para-Optoma-Optoma08.htm