Original	Sustituto	Original	Sustituto
Power	Power	Record	Rec
1	1	Info	Info
2	2	Up	Up
3	3	CH+	Ch +
4	4	CH-	Ch -
5	5	Down	Down
6	6	Right	Right
7	7	Vol +	Vol +
8	8	Left	Left
9	9	Vol -	Vol -
0	0	OK	Ok
SV/Timer	Guide	Clear	Exit
Pause	Pause	SP/LP	Format
Stop	Stop	Timer On/Off	AV
Play	Play	Timer On/Off	Sleep
>>	>>	Audio	Dual
<<	<<	Index	Smart

Original		Sustituto	
Dub	DUB	ECO 3D	3D
Monitor	Moni t or	APP MEDIA	Medi a

Original	Sustituto

Original	Sustituto	Original	Sustituto
Power	Power	Z	Sleep
1	1	Up / CH +	Ch +
2	2	Up / CH +	Up
3	3	Left / Vol -	Left
PIP	List	Left / Vol -	Vol -
4	4	OK	Ok
5	5	Right / Vol +	Right
6	6	Right / Vol +	Vol +
Format	Format	TXT	Smart
7	7	Down / CH -	Down
8	8	Down / CH -	Ch -
9	9	TV-G	TV/R
?	D. Menu	Record	Rec
0	0	DUB.	Options
Mute	Mute	Index	Media
Info	Info	Audio	Dual
Z	AV	Monitor	Text