Mandis shop

Aiwa RC-CD502

Original		Sustituto	
	Open/Close	SURROUND	Eject / Surround
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
▶II	Play	SLOW ▶	Play / Slow
▶II	Pause	STEP - FREEZE II	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
◀◀	<< Tuning	TUNE- ◀◀	<< / Tune-
◀◀	I<< Skip	PRESET- ⏮	I<< / Preset-

Original		Sustituto	
▶▶	Skip >>I	PRESET+ ⏭	>>I / Preset+
▶▶	Tuning >>	TUNE+ ▶▶	>> / Tune+
BAND	Band	TOP MENU D.MENU	D.Menu / Top
FM MODE	FM Mode	PROGRAM TV/RADIO	TV/Radio /
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
EQ	EQ	EQ SUBTITLE	Subtitle / EQ
SET	Set	HOME MENU	Menu / Home

https://mandisremotes.com/es/Aiwa/1064923-25545-mando-de-sustitucion-para-Aiwa-RC-CD502.html