Mandis shop

Philips 996510062911

Original		Sustituto	
	Power		Power
OPTICAL	Optical	CD - STB 3	3
AUDIO-IN	Audio In	DVD 2	2
COAX	Coax	TV 1	1
SURR	Surr.	SURROUND	Eject / Surround
BASS −	Bass-	TUNE-	<< / Tune-
+ BASS	Bass+	TUNE+	>> / Tune+
TREBLE −	Treble-	PRESET-	I<< / Preset-
+ TREBLE	Treble+	PRESET+	>>I / Preset+
+ VOLUME	Vol +	+ VOL	Vol +
VOLUME −	Vol -	VOL −	Vol -
	Mute	DIMMER MUTE	Mute / Dimmer
AUX	AUX	AUX - HDD 7	7
Bluetooth	Bluetooth	BLUETOOTH 9	9

Original	Sustituto