Original	Sustituto	Original	Sustituto
CD	SHIFT + CD-STB 3 (Shift + 3)	DISCO 5	TAPE 5 (5)
Disc Skip	MEDIA DISPLAY (Display / Media)	CAR 6	TUNER 6 (6)
Sleep	TIMER SLEEP (Sleep / Timer)	JAZZ CLUB 7	AUX-HDD 7 (7)
System Power	Power	STADIUM 8	USB 8 (8)
Play	SLOW (Play / Slow)	SYMPHONY 9	BLUETOOTH 9 (9)
Pause	STEP-FREEZE (Pause / Step / Freeze)	TV NEWS 10	HDMI-SAT 0 (0)
Stop	HOLD (Stop / Hold)	TUNER	SHIFT + TUNER 6 (Shift + 6)
I<<	PRESET- (I<< / Preset-)	SHIFT	LIST SMART (Smart / List)
>>I	PRESET+ (>>I / Preset+)	11	NETFLIX SEARCH (Red / Netflix / Search)
Tape	SHIFT + TAPE 5 (Shift + 5)	12	APP REPEAT (Green / APP / Repeat)
CD Direct	LANG I/II AUDIO (Audio / Lang I/II)	>12	YouTube REPEAT A-B (Yellow / YouTube / Repeat)
Select 10	-/-- GUIDE EPG (Guide / EPG / -/--)	PHONO	SHIFT + DVD 2 (Shift + 2)
P.File	PC FAV MARKER (Fav / Marker / PC)	▲	▲ (Up)
MOVIE 1	TV 1 (1)	EQ	EQ SUBTITLE (Subtitle / EQ)
BGM 2	DVD 2 (2)	VIDEO 1 /DAT	SHIFT + TV 1 (Shift + 1)
WM 3	CD-STB 3 (3)	◄	◄ (Left)
POPS 4	VIDEO 4 (4)	►	► (Right)

Original		Sustituto		Original	Sustituto
EFFECT	Effect	TITLE SOUND	Sound / Title		
VIDEO 2	Video 2	SHIFT + VIDEO 4	Shift + 4		
▼	Down	▼	Down		
+ VOL	Vol +	+ VOL	Vol +		
FUNCTION PGM	Function	HOME MENU	Menu / Home		
BASS SYNTHE	Bass Boost	PROGRAM TV/ RADIO	TV/ Radio /		
SURROUND MODE	Surround Mode	SHIFT + SURROUND ⏏	Shift + Eject / Surround		
SURROUND LEVEL	Surround Level	SURROUND ⏏	Eject / Surround		
VOL −	Vol -	VOL −	Vol -		

Original		Sustituto	
CD	CD	CD-STB 3	3
SYSTEM POWER	System Power		Power
TAPE	Tape	TAPE 5	5
<<	<< Deck A	TUNE- <<	<< / Tune-
<<	<< Deck B	SHIFT + TUNE- <<	Shift + << /
<	< Deck A	<	Left
<	< Deck B	SHIFT + <	Shift + Left
>	Deck A >	SLOW >	Play / Slow
>	Deck B >	SHIFT + SLOW >	Shift + Play /
>>	>> Deck A	TUNE+ >>	>> / Tune+
>>	>> Deck B	SHIFT + TUNE+ >>	Shift + >> /
■	Stop Deck A	HOLD ■	Stop / Hold
■	Stop Deck B	SHIFT + HOLD ■	Shift + Stop /
II	Pause Deck A	STEP-FREEZE II	Pause / Step / Freeze
II	Pause Deck B	SHIFT + STEP-FREEZE II	Shift + Pause / Step /
O	O Deck A	OK	OK
O	O Deck B	SHIFT + OK	Shift + OK

Original		Sustituto	
●	Rec Deck A	REC MODE ●	Rec / Rec Mode
●	Rec Deck B	SHIFT + REC MODE ●	Shift + Rec / Rec Mode
TUNER	Tuner	TUNER 6	6
PHONO	Phono	DVD 2	2
VIDEO 1 /DAT	Video 1 / DAT	TV 1	1
VIDEO 2	Video 2	VIDEO 4	4
+ VOL	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -

Original	Sustituto	Original	Sustituto
CD	SHIFT + 3 (Shift + 3)	VIDEO 2	SHIFT + 4 (Shift + 4)
System Power	Power	VOL +	VOL + (Vol +)
Tape	SHIFT + 5 (Shift + 5)	VOL −	VOL − (Vol -)
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
10	GUIDE EPG (Guide / EPG / -/--)		
Tuner	SHIFT + 6 (Shift + 6)		
Shift	SMART (Smart / List)		
Phono	SHIFT + 2 (Shift + 2)		
Video 1 / DAT	SHIFT + 1 (Shift + 1)		

Original	Sustituto	Original	Sustituto
CD — CD	SHIFT + CD-STB 3 — Shift + 3	VIDEO 1 /DAT — Video 1 / DAT	SHIFT + TV 1 — Shift + 1
SYSTEM POWER — System Power	Power	VIDEO 2 — Video 2	SHIFT + VIDEO 4 — Shift + 4
TAPE — Tape	SHIFT + TAPE 5 — Shift + 5	VOL + — Vol +	VOL + — Vol +
SELECT 10 — Select 10	LIST SMART — Smart / List	VOL − — Vol -	VOL − — Vol -
P.FILE 1-5 — P. File	MEDIA DISPLAY — Display / Media		
MOVIE 1 — 1/ Movie	TV 1 — 1		
BGM 2 — 2/ BGM	DVD 2 — 2		
WM 3 — 3/ WM	CD-STB 3 — 3		
POPS 4 — 4/ POPS	VIDEO 4 — 4		
DISCO 5 — 5/ Disco	TAPE 5 — 5		
CAR 6 — 6/ CAR	TUNER 6 — 6		
JAZZ CLUB 7 — 7/ Jazz Club	AUX-HDD 7 — 7		
STADIUM 8 — 8/ Stadium	USB 8 — 8		
SYMPHONY 9 — 9/ Symphony	BLUETOOTH 9 — 9		
TV NEWS 10 — 10/ TV News	HDMI-SAT 0 — 0		
TUNER — Tuner	SHIFT + TUNER 6 — Shift + 6		
PHONO — Phono	SHIFT + DVD 2 — Shift + 2		