Mandis shop

# Samsung DJ 9600114S

| Original | | Sustituto | | Original | Sustituto |
|---|---|---|---|---|---|
| Power | Power | | Power | | |
| Auto | Auto | TV 1 | 1 | | |
| Recharging | Recharging | LIST SMART | Smart / List | | |
| Spot | Spot | DVD 2 | 2 | | |
| Max | Max | CD - STB 3 | 3 | | |
| Start/Stop | Start/Stop | OK | OK | | |
| | Up | | Up | | |
| | Right | | Right | | |
| | Left | | Left | | |
| Manual | Manual | VIDEO 4 | 4 | | |
| Edge | Edge | TUNER 6 | 6 | | |
| Clock | Clock | HOME MENU | Menu / Home | | |
| Turbo | Turbo | TAPE 5 | 5 | | |
| Timer/Daily | Timer/Daily | TIMER SLEEP | Sleep / Timer | | |
| | Nothing | CLEAR EXIT CANCEL | Exit / Cancel / Clear | | |

https://mandis.es/es/Samsung/1668349-mando-sustituto-para-Samsung-DJ9600114S.htm