Original	Sustituto	Original	Sustituto
On	Power	DIM	Shift + Mute / Dimmer
Off	Shift + Power	Vol -	Vol -
1/ OPT 1	1	SPK A/ CD	Smart / List
2/ OPT 2	2	Up	Up
3/ COAX 1	3	SPK B/ USB	Display / Media
4/ COAX 2	4	Left	Left
5/ Phono	5	Enter	OK
6/ Line 1	6	Right	Right
7/ Line 2	7	Menu/ SRC	Menu / Home
8/ USB	8	Down	Down
9/ BT	9	Tone DFT/ OPT	Back / Return
Disp/ Info	Info / Angle	Stop/ Tone	Stop / Hold
+10/ Sleep	Guide / EPG / -/--	I <</ Preset	I << / Preset-
Scan/ Tune/ Source	>> / Tune+	Play/ AM/ FM/ DB	Play / Slow
Mute	Mute / Dimmer	Preset >>I	>>I / Preset+
Vol +	Vol +	Red/ Rand/ Tuner	Red / Netflix / Search
<<	<< / Tune-	Green/ RPT/ Blend	Green / APP / Repeat

Scan/ Tune/ Source d

Original	Sustituto	Original	Sustituto
MEMORY PROG Yellow/Prog/Memo	YouTube REPEAT A-B Yellow / YouTube / Repeat		
DELETE CLEAR Blue/Clear/Delet	Prime Video RANDOM Blue / Prime Video / Random		

Original	Sustituto	Original	Sustituto
On	Power	<<	<< / Tune-
Off	Shift + Power	DIM	Shift + Mute / Dimmer
1/ OPT 1	1	Vol -	Vol -
2/ OPT 2	2	SPK A/ CD	Smart / List
3/ COAX 1	3	Up	Up
4/ COAX 2	4	SPK B/ USB	Display / Media
5/ Phono	5	Left	Left
6/ Line 1	6	Enter	OK
7/ Line 2	7	Right	Right
8/ USB	8	Menu/ SRC	Menu / Home
9/ BT	9	Down	Down
Disp/ Info	Info / Angle	Tone DFT/ OPT	Back / Return
0	0	Eject/ Auto Tune	Eject / Surround
+10/ Sleep	Guide / EPG / -/--	Stop/ Tone	Stop / Hold
Scan/ Tune/ Source	>> / Tune+	Pause	Pause / Step / Freeze
Mute	Mute / Dimmer	I << Preset	I << / Preset-
Vol +	Vol +	Play/ AM/ FM/ DB	Play / Slow

Original	Sustituto	Original	Sustituto
Preset >>I	>>I / Preset+		
Red/ Rand/ Tuner	Red / Netflix / Search		
Green/ RPT/ Blen	Green / APP / Repeat		
Yellow/ Prog/ Memo	Yellow / YouTube / Repeat		
Blue/ Clear/ Delet	Blue / Prime Video / Random		

Original		Sustituto	
ON	On		Power
OFF	Off	SHIFT +	Shift + Power
INFO DISP	Disp/Info	ANGLE INFO	Info / Angle
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOL +	Vol +	VOL +	Vol +
DIM	DIM	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
VOL -	Vol -	VOL -	Vol -
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
SRC MENU	Menu/SRC	HOME MENU	Menu / Home
	Down		Down
TONE	Stop/Tone	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze
PRESET	I<< Preset	PRESET-	I<< / Preset-
AM/FM/DB	Play/AM/FM/DB	SLOW	Play / Slow

Original		Sustituto	
PRESET	Preset >>I	PRESET+	>>I / Preset+
TUNER MODE RAND	Red/Rand/Tuner	NETFLIX SEARCH	Red / Netflix / Search
BLEND RPT	Green/RPT/Blen	APP REPEAT	Green / APP / Repeat

Original		Sustituto	
ON	On		Power
OFF	Off	SHIFT +	Shift + Power
OPT 1 1	1/OPT 1	TV 1	1
OPT 2 2	2/OPT 2	DVD 2	2
COAX 1 3	3/COAX 1	CD-STB 3	3
COAX 2 4	4/COAX 2	VIDEO 4	4
PHONO 5	5/Phono	TAPE 5	5
LINE 1 6	6/Line 1	TUNER 6	6
LINE 2 7	7/Line 2	AUX-HDD 7	7
USB 8	8/USB	USB 8	8
BT 9	9/BT	BLUETOOTH 9	9
INFO DISP	Disp/Info	ANGLE INFO	Info / Angle
0	0	HDMI-SAT 0	0
SCAN TUNE SOURCE	Scan/Tune/Source	TUNE+	>> / Tune+
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOL	Vol +	VOL	Vol +
SCAN TUNE SOURCE	<<	TUNE-	<< / Tune-

Original		Sustituto	
VOL	Vol -	VOL	Vol -
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
PRESET	I<< Preset	PRESET-	I<< / Preset-
AM/FM/DB	Play/AM/FM/DB	SLOW	Play / Slow
PRESET	Preset >>I	PRESET+	>>I / Preset+
TUNER MODE RAND	Red/Rand/Tuner	NETFLIX SEARCH	Red / Netflix / Search
BLEND RPT	Green/RPT/Blen	APP REPEAT	Green / APP / Repeat
MEMORY PROG	Yellow/Prog/Memo	YouTube REPEAT A-B	Yellow / YouTube / Repeat
DELETE CLEAR	Blue/Clear/Delet	Prime Video RANDOM	Blue / Prime Video / Random

Scan/Tune/Source