Mandis shop

DRAKE COSMOTEC INTERN

Original		Sustituto	
ON / OFF	On/Off		Power
PRGM MODE	Menu	HOME MENU	Menu / Home
E ANT	Ant E	PRESET-	I<< / Preset-
ANT W	Ant W	PRESET+	>>I / Preset+
ANT W	Menu Right		Right
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
STORE	Store	LIST SMART	Smart / List
FINE TUNE	Menu Left		Left
FINE TUNE	Tune-	TUNE-	<< / Tune-
FINE TUNE	Tune+	TUNE+	>> / Tune+
SOURCE	Audio	LANG I/II AUDIO	Audio / Lang I/II
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
SELECT	Select	OK	OK
4	4	VIDEO 4	4
5	5	TAPE 5	5

Original		Sustituto	
6	6	TUNER 6	6
VOLUME	Volume+	VOL +	Vol +
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOLUME	Volume-	VOL -	Vol -
CH	Menu Down		Down
CH	CH-	CH PAGE -	CH- / Page-
0	0	HDMI - SAT 0	0
CH	Menu Up		Up
CH	CH+	CH PAGE +	CH+ / Page+