Mandis shop

Original		Sustituto	
STANDBY	Standby		Power
OPEN/CLOSE	Open / Close	SURROUND	Eject / Surround
PROG	Prog	PROGRAM TV/RADIO	TV/Radio /
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TITLE	Title	SHIFT +	TITLE SOUND Shift + Sound / Title
DISPLAY	Display	MEDIA DISPLAY	Display / Media
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
MENU	Menu	HOME MENU	Menu / Home
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
RETURN	Return	RETURN BACK	Back / Return
▲	Up		Up
◀	Left / AM		Left
SELECT	Select		OK
▶	Right / FM		Right
▼	Down		Down

Original		Sustituto	
PLAY/PAUSE	Play/Pause	SLOW	Play / Slow
STOP	Stop	HOLD	Stop / Hold
SKIP TUNE	I<< Skip / Tune-	PRESET-	I<< / Preset-
SKIP TUNE	I<< Skip / Tune-	SHIFT +	TUNE- Shift + << /
SKIP TUNE	Skip >>I / Tune+	PRESET+	>>I / Preset+
SKIP TUNE	Skip >>I / Tune+	SHIFT +	TUNE+ Shift + >> /
SEARC	<< Search	TUNE-	<< / Tune-
SEARCH	Search >>	TUNE+	>> / Tune+
VOLUME	Volume+	VOL	Vol +
SPEAKER VOL	Speaker	TOP MENU D.MENU	D.Menu / Top
TEST TONE	Test Tone	GOTO TEXT	Text / Goto
VOLUME	Volume-	VOL	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
SOUND EFFECTS	Sound Effects	TITLE SOUND	Sound / Title
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
MODE	Mode	LIST SMART	Smart / List
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II

Original		Sustituto		Original	Sustituto
ANGLE	Angle	ANGLE INFO	Info / Angle		
SEARCH MODE	Search Mode	NETFLIX SEARCH	Red / Netflix / Search		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		