Mandis shop

Panasonic N2QAYA000116

Original		Sustituto	
	Power		Power
AUTO SETUP	Auto Setup	OPT-TOOLS SETUP	Setup / OPT /
COMPUTER 1	Computer 1	PC FAV MARKER	Fav / Marker / PC
COMPUTER 1	Computer 1	NETFLIX SEARCH	Red / Netflix / Search
COMPUTER 1	Computer 1	TV 1	1
COMPUTER 2	Computer 2	DVD 2	2
COMPUTER 2	Computer 2	APP REPEAT	Green / APP / Repeat
HDMI	HDMI	HDMI - SAT 0	0
HDMI	HDMI	Prime Video RANDOM	Blue / Prime Video / Random
VIDEO	Video	VIDEO 4	4
VIDEO	Video	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MEMORY VIEWER USB DISPLAY NETWORK	Memory Viewer/USB	MEDIA DISPLAY	Display / Media
MEMORY VIEWER USB DISPLAY NETWORK	Memory Viewer/USB	USB 8	8
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right

Original		Sustituto	
	Down		Down
MENU	Menu	HOME MENU	Menu / Home
ASPECT	Aspect	SIZE ZOOM	Zoom / Size
KEYSTONE	Keystone	GOTO TEXT	Text / Goto
INFO.	Info	ANGLE INFO	Info / Angle
FREEZE	Freeze	STEP-FREEZE	Pause / Step / Freeze
AV MUTE	AV Mute	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
P-TIMER	P. Timer	TIMER SLEEP	Sleep / Timer
LAMP	Lamp	LIST SMART	Smart / List
+ D.ZOOM	D. Zoom+	+ CH PAGE	CH+ / Page+
+ VOLUME	Vol +	+ VOL	Vol +
IMAGE	Image	FORMAT PICTURE	Picture / Format
DAYLIGHT VIEW	Daylight View	TOP MENU D.MENU	D. Menu / Top
D.ZOOM –	D. Zoom-	CH PAGE –	CH- / Page-
VOLUME –	Vol -	VOL –	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer

https://mandis.es/es/Panasonic/1667-694-mando-sustituto-para-Panasonic-N2QAYA000116.htm