Original		Sustituto	
	Power		Power
	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
SUBTITLE Q.MENU	Q.Menu/Subtitle	HOME MENU	Menu / Home
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
AD	AD	LANG I/II AUDIO	Audio / Lang I/II
INPUT	Input	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LIST	List	SHIFT + LIST SMART	Shift + Smart / List
0	0	HDMI-SAT 0	0

Original		Sustituto	
Q.VIEW	Q.View	TOP MENU D.MENU	D.Menu / Top
	Vol +	VOL +	Vol +
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
P PAGE	P+	CH PAGE +	CH+ / Page+
	Vol -	VOL -	Vol -
INFO	Info	ANGLE INFO	Info / Angle
P PAGE	P-	CH PAGE -	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
SETTINGS	Settings	OPT-TOOLS SETUP	Setup / OPT /
SMART	Smart	LIST SMART	Smart / List
MY APPS	My APPS	MEDIA DISPLAY	Display / Media
TEXT	Text	GOTO TEXT	Text / Goto
	Up		Up
T.OPT	T.Opt	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
	Left		Left
OK	OK	OK	OK
	Right		Right

Original		Sustituto		Original	Sustituto
BACK	Back	RETURN BACK	Back / Return		
	Down		Down		
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
APP/*	APP/*	SHIFT + APP REPEAT	Shift + Green / APP /		
REC/*	Rec/*	REC MODE	Rec / Rec Mode		
LIVE TV	Stop/Line Tv	HOLD	Stop / Hold		
	<<	TUNE-	<< / Tune-		
	Play	SLOW	Play / Slow		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	>>	TUNE+	>> / Tune+		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		