Original		Sustituto	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	Rec	REC MODE	Rec / Rec Mode
	<<	TUNE-	<< / Tune-
	>>/[≡]	TUNE+	>> / Tune+
	I-II/[≡ ≡]	LANG I/II AUDIO	Audio / Lang I/II
	Radio	SURROUND	Eject / Surround
	[+]	SIZE ZOOM	Zoom / Size
	[<>]/Timer	TIMER SLEEP	Sleep / Timer
	Tv	PROGRAM TV/RADIO	TV/Radio /
	[≡]	GOTO TEXT	Text / Goto
	Source/[?]	RDS AV INPUT	AV / Input / RDS
	Menu	HOME MENU	Menu / Home
	Up		Up

Original		Sustituto	
	[i +]	ANGLE INFO	Info / Angle
	Left		Left
	PC/OK	OK	OK
	Right		Right
	Down		Down
	[X]	RETURN BACK	Back / Return
	Vol +	VOL	Vol +
	[ ]/Smart	LIST SMART	Smart / List
	P+	CH PAGE	CH+ / Page+
	Vol -	VOL	Vol -
	[♪]/Smart	MEDIA DISPLAY	Display / Media
	P-	CH PAGE	CH- / Page-
	1	TV 1	1
	2	DVD 2	2
	3	CD-STB 3	3
	4	VIDEO 4	4
	5	TAPE 5	5

Original		Sustituto		Original	Sustituto
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
ACTIVE CONTROL	[-O-]/Active Control	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
P<P	P<P	PC FAV MARKER	Fav / Marker / PC		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green/[■]	APP REPEAT	Green / APP / Repeat		
	Yellow/[←■]	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
MODE	Prog	SHIFT +	PROGRAM TV/RADIO Shift + TV/Radio / Program		

Original	Sustituto
Power	Power
Mute	Mute / Dimmer
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
<<	<< / Tune-
>>	>> / Tune+
I-II / [≡I ≡]	Audio / Lang I/II
[+]	Zoom / Size
[≡]	Text / Goto
Source/[?]	AV / Input / RDS
Menu	Menu / Home
Up	Up
[i+]	Info / Angle
Left	Left
PG/OK	OK
Right	Right

Original	Sustituto
Down	Down
Vol +	Vol +
P+	CH+ / Page+
Vol -	Vol -
P-	CH- / Page-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0

Original	Sustituto
Power	Power
Mute	Mute / Dimmer
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Rec	Rec / Rec Mode
<<	<< / Tune-
>>/[≡]	>> / Tune+
I-II/[≡≡]	Audio / Lang I/II
[<>]/Timer	Picture / Format
[+]	Zoom / Size
Source/[?]	AV / Input / RDS
Menu	Menu / Home
Up	Up
[i+]	Info / Angle
Left	Left
PG/OK	OK

Original	Sustituto
Right	Right
Down	Down
Vol +	Vol +
P+	CH+ / Page+
Vol -	Vol -
P-	CH- / Page-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Red	Red / Netflix / Search

Original	Sustituto	Original	Sustituto
Green/[■]	APP / REPEAT — Green / APP / Repeat		
Yellow/[←■]	YouTube / REPEAT A-B — Yellow / YouTube / Repeat		
Blue	Prime Video / RANDOM — Blue / Prime Video / Random		