Original		Sustituto	
RECORD	Record	REC MODE	Rec / Rec Mode
STANDBY	Standby		Power
	Up		Up
	Left		Left
	Right		Right
MENU	Menu	HOME MENU	Menu / Home
	Down		Down
OK	OK	OK	OK
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TIMER	Timer	TIMER SLEEP	Sleep / Timer
SELECT	Select	PC FAV MARKER	Fav / Marker / PC
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6

Original		Sustituto	
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
	Vol + Tv	VOL +	Vol +
0	0	HDMI - SAT 0	0
P	P+	CH PAGE +	CH+ / Page+
	Mute Tv	DIMMER MUTE	Mute / Dimmer
TV	Power Tv	SHIFT +	Shift + Power
	Vol - Tv	VOL -	Vol -
	P-	CH PAGE -	CH- / Page-
	<<	TUNE-	<< / Tune-
PLAY	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
INDEX	>I / Index	PRESET+	>>I / Preset+
STOP	Stop	HOLD	Stop / Hold
STILL	>I </ Still	PRESET-	I << / Preset-
MONITOR	Monitor	RDS AV INPUT	AV / Input / RDS

Original	Sustituto	Original	Sustituto
INSTANT VIEW Instant View	FORMAT PICTURE Picture / Format		
COUNTER Counter	RETURN BACK Back / Return		