Mandis shop

Sony RMT-708

Original		Sustituto	
PLAY	Play	SLOW ▶	Play / Slow
START/STOP	Start/Stop	⏻	Power
START/STOP	Start/Stop	REC MODE ●	Rec / Rec Mode
REW	<<	TUNE- ◀◀	<< / Tune-
FF	>>	TUNE+ ▶▶	>> / Tune+
STOP	Stop	HOLD ■	Stop / Hold
	T	+ CH PAGE	CH+ / Page+
PAUSE	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
SLOW	I>/Slow	▶	Right
SLOW	I>/Slow	SHIFT + SLOW ▶	Shift + Play /
	W	CH PAGE −	CH- / Page-
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Original	Sustituto

https://mandisremotes.com/es/Sony/1068047-6337-mando-de-sustitucion-para-Sony-RMT-708-146757423.html