Mandis shop

APACER AL460

Original		Sustituto	
POWER	Power		Power
HOME	Home	HOME MENU	Menu / Home
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
DISPLAY	Display	MEDIA DISPLAY	Display / Media
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
VOL-	Vol-	VOL	Vol-
VOL+	Vol+	VOL	Vol+
	Up		Up
	Left		Left
ENTER/PLAY	Enter / Play	OK	OK
ENTER/PLAY	Enter / Play	SLOW	Play / Slow
	Right		Right
STOP	Stop	HOLD	Stop / Hold
	Down		Down
BACK	Back	RETURN BACK	Back / Return
FR	<< FR	TUNE-	<< / Tune-
FF	FF >>	TUNE+	>> / Tune+

Original		Sustituto	
PAUSE/STEP	Pause / Step	STEP-FREEZE	Pause / Step / Freeze
PREV	I<< Prev	PRESET-	I<< / Preset-
NEXT	Next >>I	PRESET+	>>I / Preset+
SLOW	Slow	SHIFT + SLOW	Shift + Play /
SLOW	Slow	SURROUND	Eject / Surround
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
TV SYSTEM	TV System	LIST SMART	Smart / List
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
OPTION	Option	TOP MENU D.MENU	D.Menu / Top

https://mandisremotes.com/es/APACER/1068102-97345-mando-de-sustitucion-para-APACER-AL460.html