Mandis shop

# POLK AUDIO 981307102280K

| Original | | Sustituto | |
|---|---|---|---|
| | Power | | Power |
| 1 | HDMI 1 | 1 | 1 |
| 2 | HDMI 2 | 2 | 2 |
| 3 | HDMI 3 | 3 | 3 |
| TV | TV | PROGRAM TV/RADIO | TV/Radio / |
| | Bluetooth | 9 | 9 |
| BASS | Bass+ | | Up |
| VOL | Vol + | VOL | Vol + |
| VOICE | Voice+ | CH PAGE | CH+ / Page+ |
| BASS | Bass- | | Down |
| VOL | Vol - | VOL | Vol - |
| VOICE | Voice- | CH PAGE | CH- / Page- |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| MOVIE | Movie | EQ SUBTITLE | Subtitle / EQ |
| MUSIC | Music | LANG I/II AUDIO | Audio / Lang I/II |
| NIGHT | Night | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| 3D | 3D | FORMAT PICTURE | Picture / Format |

| Original | | Sustituto | |
|---|---|---|---|
| SPORT | Sport | RETURN BACK | Back / Return |
| VOLUME SURROUND | Volume Surround- | SHIFT + VOL | Shift + Vol - |
| VOLUME SURROUND | Volume | SHIFT + VOL | Shift + Vol + |
| BALANCE L | Balance L | | Left |
| BALANCE R | Balance R | | Right |

https://mandis.es/es/POLK-AUDIO-981307102280K-mando-sustitucion-para-POLK-AUDIO-981307102280K.htm