Mandis shop

WAVE- MUSIC- SYSTEM

Original		Sustituto	
On Off	On/Off / Stop		Power
Sleep	Sleep	TIMER SLEEP	Sleep / Timer
Stop Alarm Mute	Mute	DIMMER MUTE	Mute / Dimmer
FM AM	FM/AM	SHIFT + TUNER 6	Shift + 6
FM AM	FM/AM	NETFLIX SEARCH	Red / Netflix / Search
CD	CD	APP REPEAT	Green / APP / Repeat
CD	CD	SHIFT + CD-STB 3	Shift + 3
[▬]	[▬]	YouTube REPEAT A-B	Yellow / YouTube / Repeat
[▬]	[▬]	SHIFT + AUX-HDD 7	Shift + 7
Volume	Vol +	VOL +	Vol +
1	Presets 1	TV 1	1
2	Presets 2	DVD 2	2
3	Presets 3	CD-STB 3	3
Volume	Vol -	VOL −	Vol -
4	Presets 4	VIDEO 4	4
5	Presets 5	TAPE 5	5
6	Presets 6	TUNER 6	6

Original		Sustituto	
⏮	I << Seek/Track	PRESET- ⏮	I << / Preset-
⏭	Seek/Track >>I	PRESET+ ⏭	>>I / Preset+
▶II	Play	SLOW ▶	Play / Slow
▶II	Pause	STEP-FREEZE II	Pause / Step / Freeze
⏏	Stop	HOLD ■	Stop / Hold
⏏	Eject	SURROUND ⏏	Eject / Surround
<	< Tune/Playlis	TUNE- ◀◀	<< / Tune-
>	Tune/Playlist	TUNE+ ▶▶	>> / Tune+
−	Time-	CH PAGE −	CH- / Page-
+	Time+	CH PAGE +	CH+ / Page+
Play Mode	Play Mode	LIST SMART	Smart / List
Alarm On/Off	Alarm On/Off	OK	OK
Wake To	Alarm Wake To	▶	Right
Alarm Time	Alarm	◀	Left
Alarm Time	Alarm	HOME MENU	Menu / Home

https://mandis.es/es/1686-mando-sustitucion-para-BOSE-Wave-Music-System.html