Original		Sustituto	
POWER	Power		Power
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
ANGLE	Angle	ANGLE INFO	Info / Angle
OPEN /CLOSE	Open/Close	SURROUND	Eject / Surround
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
REPEAT A-B	Repeat A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MENU	Menu	HOME MENU	Menu / Home
LAST MEMO	Last Memo	PC FAV MARKER	Fav / Marker / PC
CONDITION	Condition	SIZE ZOOM	Zoom / Size
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
TITLE	Title	TITLE SOUND	Sound / Title
	Up		Up
RETURN	Return	RETURN BACK	Back / Return
DISPLAY	Display	MEDIA DISPLAY	Display / Media
PGM	PGM	PROGRAM TV/RADIO	TV/Radio /
	Left		Left

Original		Sustituto	
ENTER	Enter	OK	OK
	Right		Right
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CHP/TM	CHP/TM	OPT-TOOLS SETUP	Setup / OPT /
PREV	I<< Prev	PRESET-	I<< / Preset-
	Down		Down
NEXT	Next >>I	PRESET+	>>I / Preset+
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original		Sustituto		Original	Sustituto
0	0	0	0		
<< REV	<< / Tune-				
Play	Play / Slow				
FWD >>	>> / Tune+				
Jog Mode 1	Shift + 1				
Jog Mode 2	Shift + 2				
FL Dimmer	Mute / Dimmer				
Mode	Picture / Format				
Stop	Stop / Hold				
Pause	Pause / Step / Freeze				

Original		Sustituto	
POWER	Power		Power
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
ANGLE	Angle	ANGLE INFO	Info / Angle
OPEN /CLOSE	Open/Close	SURROUND	Eject / Surround
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
REPEAT A-B	Repeat A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MENU	Menu	HOME MENU	Menu / Home
LAST MEMO	Last Memo	PC FAV MARKER	Fav / Marker / PC
CONDITION	Condition	SIZE ZOOM	Zoom / Size
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
TITLE	Title	TITLE SOUND	Sound / Title
	Up		Up
RETURN	Return	RETURN BACK	Back / Return
DISPLAY	Display	MEDIA DISPLAY	Display / Media
PGM	PGM	PROGRAM TV/ RADIO	TV/ Radio /
	Left		Left

Original		Sustituto	
ENTER	Enter	OK	OK
	Right		Right
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CHP/TM	CHP/TM	OPT-TOOLS SETUP	Setup / OPT /
PREV	I<< Prev	PRESET-	I<< / Preset-
	Down		Down
NEXT	Next >>I	PRESET+	>>I / Preset+
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original		Sustituto		Original	Sustituto
0	0	HDMI - SAT 0	0		
REV <<	<< REV	TUNE- <<	<< / Tune-		
PLAY ▶	Play	SLOW ▶	Play / Slow		
FWD >>	FWD >>	TUNE+ >>	>> / Tune+		
JOG MODE	Jog Mode 1	SHIFT + TV 1	Shift + 1		
JOG MODE	Jog Mode 2	SHIFT + DVD 2	Shift + 2		
FL DIMMER	FL Dimmer	DIMMER MUTE	Mute / Dimmer		
MODE	Mode	FORMAT PICTURE	Picture / Format		
STOP ■	Stop	HOLD ■	Stop / Hold		
PAUSE ❚❚	Pause	STEP - FREEZE ❚❚	Pause / Step / Freeze		