| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Standby | Power | Down | Down |
| Mute | Mute | Right | Right |
| P/N | Smart | Left | Left |
| Open/Close | Eject | OK | Ok |
| << | << | Vol + | Vol + |
| >> | >> | Vol - | Vol - |
| Play/Pause | Play | 1 | 1 |
| Stop | Stop | 2 | 2 |
| I << | I << | 3 | 3 |
| >>I | >>I | 4 | 4 |
| Setup | Options | 5 | 5 |
| Source | AV | 6 | 6 |
| Info | Info | 7 | 7 |
| Return/Exit | Exit | 8 | 8 |
| CH+ | Ch + | 9 | 9 |
| CH- | Ch - | 0 | 0 |
| Up | Up | Slow | Back |

| Original | | Sustituto | |
|---|---|---|---|
| GOTO | Goto | APP MEDIA | Media |
| PROGRAM | Program | PROG SLEEP | Sleep |
| TITLE/TTX | Title/TTX | REPEAT TEXT | Text |
| AUDIO | Audio | SOUND DUAL | Dual |
| SUBTITLE | Subtitle | AD SUBT | Subt |
| REPEAT | Red/Repeat | A | Red |
| A-B | Green/A-B | B | Green |
| MENU | Yellow/Menu | C | Yellow |
| ANGLE | Blue/Angle | D | Blue |
| EPG | EPG | -/-- GUIDE | Guide |
| FAVORITE | Favorite | FAV PRE-CH | Pre Ch |
| TV/RADIO | Tv/Radio | SEARCH TV/R | TV/R |
| ZOOM | Zoom | SHIFT + | ZOOM Shift + Eject |

| Original | Sustituto |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |