Original	Sustituto	Original	Sustituto
POWER Power	Power	Stop CD	HOLD Stop / Hold
RESET Reset	RETURN BACK Back / Return	Play CD	SLOW Play / Slow
REC/ MUTE Rec Mute	REC MODE Rec / Rec Mode	PROGRAM Program	PROGRAM TV/ RADIO TV/ Radio /
SLEEP Sleep	TIMER SLEEP Sleep / Timer	CANCEL Cancel	CLEAR EXIT CANCEL Exit / Cancel / Clear
<< Deck	Down	DIRECT Direct	SIZE ZOOM Zoom / Size
Deck >>	Up	TUNER Tuner	SHIFT + TUNER 6 Shift + 6
Stop Deck	OK OK	FUNCTION Function	HOME MENU Menu / Home
< Deck	Left	1 1	TV 1 1
Deck >	Right	2 2	DVD 2 2
EDIT Edit	LIST SMART Smart / List	3 3	CD - STB 3 3
RANDOM Random	Prime Video RANDOM Blue / Prime Video / Random	4 4	VIDEO 4 4
REPEAT Repeat	APP REPEAT Green / APP / Repeat	5 5	TAPE 5 5
I << CD	PRESET- I << / Preset-	6 6	TUNER 6 6
>>I CD	PRESET+ >>I / Preset+	7 7	AUX - HDD 7 7
TIME SIDE A/B Time Side AB	YouTube REPEAT A-B Yellow / YouTube / Repeat	8 8	USB 8 8
<< CD	TUNE- << / Tune-	9 9	BLUETOOTH 9 9
>> CD	TUNE+ >> / Tune+	10 10	HDMI - SAT 0 0

Original		Sustituto		Original	Sustituto
PRES	Preset Down	SHIFT + PRESET-	Shift + I<< / Preset-		
RESET	Preset Up	SHIFT + PRESET+	Shift + >>I / Preset+		
MEMO	Memo	MEDIA DISPLAY	Display / Media		
+10	+10	PC FAV MARKER	Fav / Marker / PC		
TUNI	Tuning Down	SHIFT + TUNE-	Shift + << /		
UNING	Tuning Up	SHIFT + TUNE+	Shift + >> /		
BAND	Band	NETFLIX SEARCH	Red / Netflix / Search		
VOLUME	Volume+	+ VOL	Vol +		
RDS	RDS	RDS AV INPUT	AV / Input / RDS		
PTY	PTY	EQ SUBTITLE	Subtitle / EQ		
CT	CT	TOP MENU D.MENU	D.Menu / Top		
PANEL	Panel	FORMAT PICTURE	Picture / Format		
VOLUME	Volume-	VOL −	Vol -		