Original		Sustituto	
ON AVR Power	AVR Power On	Power	
OFF Power	AVR Power Off	SHIFT + Power	Shift + Power
Cable/Sat	Cable/Sat	SHIFT + HDMI - SAT 0	Shift + 0
Disc	Disc	SHIFT + DVD 2	Shift + 2
DVR	DVR	SHIFT + CD - STB 3	Shift + 3
Radio	Radio	SHIFT + TUNER 6	Shift + 6
TV	TV	SHIFT + TV 1	Shift + 1
USB	USB	SHIFT + USB 8	Shift + 8
Game	Game	SHIFT + VIDEO 4	Shift + 4
Media Server	Media Server	SHIFT + BLUETOOTH 9	Shift + 9
Network	Network	SHIFT + TAPE 5	Shift + 5
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
Audio Effects	Audio Effects	LANG I/II AUDIO	Audio / Lang I/II
Video Modes	Video Modes	FORMAT PICTURE	Picture / Format
Surround Modes	Surround Modes	SURROUND	Eject / Surround
1	1	TV 1	1
ABC 2	2	DVD 2	2

Original		Sustituto	
DEF 3	3	CD - STB 3	3
GHI 4	4	VIDEO 4	4
JKL 5	5	TAPE 5	5
MNO 6	6	TUNER 6	6
PQRS 7	7	AUX - HDD 7	7
TUV 8	8	USB 8	8
WXYZ 9	9	BLUETOOTH 9	9
LAST	Last	RETURN BACK	Back / Return
>9 0	0	HDMI - SAT 0	0
BACK/ EXIT	Back/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
▲	Up	▲	Up
MENU	Menu	HOME MENU	Menu / Home
◀	Left	◀	Left
OK	OK	OK	OK
▶	Right	▶	Right
▼	Down	▼	Down
A	Red	NETFLIX SEARCH	Red / Netflix / Search

Original	Sustituto	Original	Sustituto
Green	Green / APP / Repeat	Sleep	Sleep / Timer
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
Vol +	Vol +		
Mute	Mute / Dimmer		
CH/ Page Up	CH+ / Page+		
Vol -	Vol -		
CH/ Page Down	CH- / Page-		
I <<	I << / Preset-		
Pause	Pause / Step / Freeze		
>>I	>>I / Preset+		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Stop	Stop / Hold		
AVR	Smart / List		
Info	Info / Angle		

Original		Sustituto	
Disc Power On		Power	
Disc Power Off		Shift + Power	
Disc		Display / Media	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
Last		Back / Return	
0		0	
Back/Exit		Exit / Cancel / Clear	
Up		Up	
Menu		Menu / Home	

Original		Sustituto	
Left		Left	
OK		OK	
Right		Right	
Down		Down	
Disc Menu		D.Menu / Top	
Red		Red / Netflix / Search	
Green		Green / APP / Repeat	
Yellow		Yellow / YouTube / Repeat	
Blue		Blue / Prime Video / Random	
Vol +		Vol +	
Mute		Mute / Dimmer	
Vol -		Vol -	
I<<		I<< / Preset-	
Pause		Pause / Step / Freeze	
>>I		>>I / Preset+	
<<		<< / Tune-	
Play		Play / Slow	

Original	Sustituto	Original	Sustituto
>>	>> / Tune+		
Rec	Rec / Rec Mode		
Stop	Stop / Hold		

Original		Sustituto	
ON Device	DVR Power On		Power
DVR	DVR	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
ABC 2	2	DVD 2	2
DEF 3	3	CD - STB 3	3
GHI 4	4	VIDEO 4	4
JKL 5	5	TAPE 5	5
MNO 6	6	TUNER 6	6
PQRS 7	7	AUX - HDD 7	7
TUV 8	8	USB 8	8
WXYZ 9	9	BLUETOOTH 9	9
>9 0	0	HDMI - SAT 0	0
	Up		Up
MENU	Menu	HOME MENU	Menu / Home
	Left		Left
	Right		Right
	Down		Down

Original		Sustituto	
+ VOL	Vol +	+ VOL	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
CH Page ▲	CH/ Page Up	+ CH PAGE	CH+ / Page+
VOL –	Vol -	VOL –	Vol -
CH Page ▼	CH/ Page Down	CH PAGE –	CH- / Page-

Original		Sustituto	
ON AVR Power	AVR Power On	Power	
OFF Power	AVR Power Off	SHIFT + Power	Shift + Power
Cable/Sat	Cable/SAT	SHIFT + HDMI - SAT 0	Shift + 0
Disc	Disc	SHIFT + DVD 2	Shift + 2
DVR	DVR	SHIFT + CD - STB 3	Shift + 3
Radio	Radio	SHIFT + TUNER 6	Shift + 6
TV	TV	SHIFT + TV 1	Shift + 1
USB	USB	SHIFT + USB 8	Shift + 8
Game	Game	SHIFT + VIDEO 4	Shift + 4
Media Server	Media Server	SHIFT + BLUETOOTH 9	Shift + 9
Network	Network	SHIFT + TAPE 5	Shift + 5
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
Audio Effects	Audio Effects	LANG I/II AUDIO	Audio / Lang I/II
Video Modes	Video Modes	FORMAT PICTURE	Picture / Format
Surround Modes	Surround Modes	SURROUND	Eject / Surround
1	1	TV 1	1
ABC 2	2	DVD 2	2

Original		Sustituto	
DEF 3	3	CD - STB 3	3
GHI 4	4	VIDEO 4	4
JKL 5	5	TAPE 5	5
MNO 6	6	TUNER 6	6
PQRS 7	7	AUX - HDD 7	7
TUV 8	8	USB 8	8
WXYZ 9	9	BLUETOOTH 9	9
LAST	Last	RETURN BACK	Back / Return
>9 0	0	HDMI - SAT 0	0
BACK/ EXIT	Back/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
▲	Up	▲	Up
MENU	Menu	HOME MENU	Menu / Home
◀	Left	◀	Left
OK	OK	OK	OK
▶	Right	▶	Right
▼	Down	▼	Down
A	Red	NETFLIX SEARCH	Red / Netflix / Search

Original	Sustituto	Original	Sustituto
Green	Green / APP / Repeat	Info	Info / Angle
Yellow	Yellow / YouTube / Repeat	Sleep	Sleep / Timer
Blue	Blue / Prime Video / Random		
Vol +	Vol +		
Mute	Mute / Dimmer		
CH/ Page Up	CH+ / Page+		
Vol -	Vol -		
CH/ Page Down	CH- / Page-		
I <<	I << / Preset-		
Pause	Pause / Step / Freeze		
>>I	>>I / Preset+		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec	Rec / Rec Mode		
Stop	Stop / Hold		
AVR	Smart / List		