Mandis shop

Hisense EN205A7H

Original		Sustituto	
	Power		Power
	Mute		Mute / Dimmer
	Movie		TV/Radio /
	Music		Audio / Lang I/II
	Vol+		Vol+
	Vol+		Up
	I<		I<< / Preset-
	I<		Left
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Pair		OK
	>I		>>I / Preset+
	>I		Right
	Vol-		Vol-
	Vol-		Down
	News		Info / Angle
	HDMI ARC		0

Original		Sustituto	
	OPT Coax		Setup / OPT /
	Bluetooth		9
	Line In		3
	USB		8

https://mandisremotes.com/es/Hisense/1066905-96374-mando-de-sustitucion-para-Hisense-EN205A7H-WT0039938.html