| Original | | Sustituto | |
|---|---|---|---|
| | Power | | Power |
| | Up / P+ | | Up |
| | Up / P+ | | CH+ / Page+ |
| | Menu | | Menu / Home |
| | Left | | Left |
| | Right | | Right |
| | Down / P- | | Down |
| | Down / P- | | CH- / Page- |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |

| Original | | Sustituto | |
|---|---|---|---|
| | - - | | Guide / EPG / -/-- |
| | 0 | | 0 |
| | P < P | | Fav / Marker / PC |
| | PP | | Back / Return |
| | Vol + | | Vol + |
| | I-II | | Audio / Lang I/II |
| | Mute | | Mute / Dimmer |
| | Vol - | | Vol - |
| | Info | | Info / Angle |
| | Red | | Red / Netflix / Search |
| | Green | | Green / APP / Repeat |
| | Yellow | | Yellow / YouTube / Repeat |
| | Blue | | Blue / Prime Video / Random |
| | [TV] | | Shift + 1 |
| | [TV] | | TV/Radio / |
| | [AV] | | AV / Input / RDS |
| | [ ≡ ] | | Text / Goto |

| Original | | Sustituto | | Original | Sustituto |
|---|---|---|---|---|---|
| TIME | [ ≡◷] | EQ SUBTITLE | Subtitle / EQ | | |
| | [ / ≡] | FORMAT PICTURE | Picture / Format | | |
| | [ ≡X] | CLEAR EXIT CANCEL | Exit / Cancel / Clear | | |
| GUIDE | [ ≡↕] | SIZE ZOOM | Zoom / Size | | |
| TITLE LANG. | [ ≡?] | MEDIA DISPLAY | Display / Media | | |
| OPEN/CLOSE TV/RADIO | [ ≡i ] | LIST SMART | Smart / List | | |

| Original | | Sustituto | |
|---|---|---|---|
| | Power | | Power |
| | Up / P+ | | Up |
| | Up / P+ | | CH+ / Page+ |
| | Menu | | Menu / Home |
| | Left | | Left |
| | Select | | OK |
| | Right | | Right |
| | Down / P- | | CH- / Page- |
| | Down / P- | | Down |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |

| Original | | Sustituto | |
|---|---|---|---|
| | 9 | | 9 |
| | +10 | | Guide / EPG / -/-- |
| | 0 | | 0 |
| | Repeat | | Green / APP / Repeat |
| | Search | | Red / Netflix / Search |
| | A→B | | Yellow / YouTube / Repeat |
| | Display | | Display / Media |
| | Audio | | Audio / Lang I/II |
| | Subtitle | | Subtitle / EQ |
| | Zoom | | Zoom / Size |
| | Prog | | TV/Radio / |
| | C | | Blue / Prime Video / Random |
| | Angle | | Info / Angle |
| | Return | | Back / Return |
| | Time | | Sleep / Timer |
| | ◀◀ | | << / Tune- |
| | ▶▶ | | >> / Tune+ |

| Original | | Sustituto | | Original | Sustituto |
|---|---|---|---|---|---|
| | ⏮ | | I << / Preset- | | |
| | ⏭ | | >>I / Preset + | | |
| | ▶/❚❚ | | Play / Slow | | |
| | ▶/❚❚ | | Pause / Step / Freeze | | |
| | ■ | | Stop / Hold | | |
| | Title | | Sound / Title | | |
| | Open / Close | | Eject / Surround | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| On/Off | Power | Menu Right | Right |
| Mute | Mute / Dimmer | Menu Down | Down |
| Txt Stop | Stop / Hold | Back | Back / Return |
| Tone+ | >> / Tune+ | Volume+ | Vol + |
| Lang | Sound / Title | Chan. Up | CH+ / Page+ |
| Menu audio | Audio / Lang I/II | Volume- | Vol - |
| Subt. List | Subtitle / EQ | Display | Display / Media |
| Txt Expand | Zoom / Size | Chan. Down | CH- / Page- |
| Sleep Timer | Sleep / Timer | 1 | 1 |
| Return TV | TV/Radio / | 2 | 2 |
| Menu video | D. Menu / Top | 3 | 3 |
| Text | Text / Goto | 4 | 4 |
| Menu | Menu / Home | 5 | 5 |
| Menu Up | Up | 6 | 6 |
| Info | Info / Angle | 7 | 7 |
| Menu Left | Left | 8 | 8 |
| OK Enter | OK | 9 | 9 |

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Guide -/-- 1. | GUIDE EPG | Guide / EPG / -/-- | |
| 0/10 | HDMI - SAT 0 | 0 | |
| 2. Fav P/C 2. | PC FAV MARKER | Fav / Marker / PC | |
| Red | NETFLIX SEARCH | Red / Netflix / Search | |
| Green | APP REPEAT | Green / APP / Repeat | |
| Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat | |
| Blue | Prime Video RANDOM | Blue / Prime Video / Random | |
| Lang | SHIFT + LANG I/II AUDIO | Shift + Audio / Lang I/II | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |