Original	Sustituto	Original	Sustituto
Mute	Mute / Dimmer	Blue	Blue / Prime Video / Random
Power	Power	Tv/DTV	Smart / List
1	1	Up	Up
2	2	Menu	Menu / Home
3	3	Left	Left
4	4	OK	OK
5	5	Right	Right
6	6	[≡]/Text	Text / Goto
7	7	Down	Down
8	8	Back	Back / Return
9	9	P+	CH+ / Page+
i	Info / Angle	Vol +	Vol +
0	0	P-	CH- / Page-
AV	AV / Input / RDS	Vol -	Vol -
Red	Red / Netflix / Search	[^]/[+]	Setup / OPT / Program
Green	Green / APP / Repeat	<<	<< / Tune-
Yellow	Yellow / YouTube / Repeat	Tv/Radio/[?]	TV/Radio /

Original	Sustituto	Original	Sustituto
Play	Play / Slow		
Guide/[♦]	Guide / EPG / -/--		
>>	>> / Tune+		
[˅]/Timer	Sleep / Timer		
Rec/Top Menu	D.Menu / Top		
I-II/[X]	Audio / Lang I/II		
Stop	Stop / Hold		
[...]/[≡i]	Subtitle / EQ		
Pause	Pause / Step / Freeze		
Zoom	Zoom / Size		
(↔)	Display / Media		
♪-PC	Sound / Title		
[■]-PC	Picture / Format		

Original		Sustituto	
	Power		Power
	Up		Up
	Menu		Menu / Home
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	Back		Back / Return
	↑		CH+ / Page+
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	↓		CH- / Page-
	Rec/Top Menu		D. Menu / Top
	Rec/Top Menu		Rec / Rec Mode
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze

Original	Sustituto

Original		Sustituto	
	Power		Power
	Up		Up
	Down		Down
	<<	TUNE-	<< / Tune-
TV/RADIO	Play	SLOW	Play / Slow
GUIDE	>>	TUNE+	>> / Tune+
TOP MENU	Rec	REC MODE	Rec / Rec Mode
	Stop	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze

Original	Sustituto