Mandis shop

# JVC RM-V760U

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Start/Stop | Power | | |
| Snap Shot | Display / Media | | |
| T | Up | | |
| << | << / Tune- | | |
| << | Left | | |
| Play | Play / Slow | | |
| Pause | Pause / Step / Freeze | | |
| >> | >> / Tune+ | | |
| >> | Right | | |
| W | Down | | |
| Info | Info / Angle | | |
| Index | Smart / List | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

https://mandisremotes.com/es/JVC/1058197-91586-mando-de-sustitucion-para-JVC-RM-V760U.html