Original		Sustituto	
ATT ⏻/I	Power / ATT		Power
DISP	Disp	MEDIA DISPLAY	Display / Media
▲	Up	CH PAGE +	CH+ / Page+
⏮	I<< / Down	PRESET- ⏮	I<< / Preset-
⏭	>>I / Up	PRESET+ ⏭	>>I / Preset+
▼	Down	CH PAGE −	CH- / Page-
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
2nd VOL VOL +	Vol +	VOL +	Vol +
2nd VOL VOL +	2nd Vol +	SHIFT + VOL +	Shift + Vol +
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
−	Vol -	VOL −	Vol -
−	2nd Vol -	SHIFT + VOL −	Shift + Vol -
▶/II	Play	SLOW ▶	Play / Slow
▶/II	Pause	STEP-FREEZE II	Pause / Step / Freeze
PHONE	Phone	-/-- GUIDE EPG	Guide / EPG / -/--
BAND/■	Band/Stop	HOLD ■	Stop / Hold

Original		Sustituto	
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
ASPECT	Aspect	FORMAT PICTURE	Picture / Format
RETURN	Return	RETURN BACK	Back / Return
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
TOP M	Top M	TOP MENU D.MENU	D.Menu / Top
△	Up	▲	Up
MENU	Menu	HOME MENU	Menu / Home
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
◁	Left	◀	Left
ENT	Enter	OK	OK

Original		Sustituto		Original	Sustituto
▷	Right	▷	Right		
*	*	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
0	0	HDMI - SAT 0	0		
#	#	PC FAV MARKER	Fav / Marker / PC		
OSD	OSD	LIST SMART	Smart / List		
▽	Down	▽	Down		
DUAL	Dual	LANG I/II AUDIO	Audio / Lang I/II		
DIRECT CLR	Direct CLR	PROGRAM TV/ RADIO	TV/Radio /		
SURROUND	Sorround	SURROUND ⏏	Eject / Surround		