Original		Sustituto	
	Power		Power
	Open/Close	ZOOM	Eject
VOL +	Vol +	VOL +	Vol +
VOL –	Vol -	VOL –	Vol -
	Mute	MUTE	Mute
F	F	TOP MENU MENU	Menu
PRESET FOLDER	Preset/Folder Up	CH +	Ch +
PRESET FOLDER	Preset/Folder	CH –	Ch -
JUKEBOX /MEMORY	Jukebox/Memor	HOME SMART	Smart
AUTO DJ	Auto DJ	SETTINGS OPT	Options
DELETE	Delete	CLEAR EXIT	Exit
REPEAT	Repeat	REPEAT TEXT	Text
	>>I		>>I
	Tuning+		Right
	Tuning-		Left
	I <<		I <<
	Play	PLAY MODE	Play

Original		Sustituto	
	Pause		Pause
	Stop		Stop
SOUND EFFECT	Sound Effect	SOUND DUAL	Dual
REGION EQ	Region EQ	SEARCH TV/R	TV/R
INFO /SLEEP	Info/Sleep	DISPLAY INFO	Info
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CLOCK	Clock	SHIFT + TIMER AV	Shift + AV
ALARM	Alarm	APP MEDIA	Media

Original		Sustituto	
VOICE CANCELLER	Voice Cancelle	TIMER AV	AV
DJ EFFECT	DJ Effect	PICTURE FORMAT	Format
RDS/SET	RDS/Set	ECO 3D	3D
PTY	PTY	AD SUBT	Subt
USB REC	USB Rec	REC MODE	Rec
+	DJ Level +	▲	Up
–	DJ Level -	▼	Down
#	Key Change #	A	Red
b	Key Changer b	B	Green

Original	Sustituto