Original		Sustituto	
	Power		Power
	HDMI / Control	HOME SMART	Smart
	Rec	REC MODE	Rec
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
	<<		<<
	>>		>>
	I<<		I<<
	>>I		>>I
ZOOM	Red/ Zoom/ ↑↓	A	Red
REPEAT	Green/ Repeat / ↓	B	Green
ROOT	Yellow/ Root	C	Yellow
TITLE	Blue/ Title	D	Blue
SCREEN	Screen	PICTURE FORMAT	Format
LANG	Lang	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt

Original		Sustituto	
	Internet / PIP	APP MEDIA	Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TEXT	Text	REPEAT TEXT	Text
INFO	Info	DISPLAY INFO	Info
SOURCE	Source	TIMER AV	AV
OK	OK	OK	Ok
	Up		Up
	Down		Down

Original		Sustituto	
	Right		Right
	Left		Left
P+	P+	CH +	Ch +
P-	P-	CH −	Ch -
V+	Vol +	VOL +	Vol +
V-	Vol -	VOL −	Vol -
MENU	Menu	TOP MENU / MENU	Menu
	Mute	MUTE	Mute
RETURN	Return	RETURN / BACK	Back
SWAP	Swap	FAV / PRE-CH	Pre Ch
FAV	FAV	SHIFT + FAV / PRE-CH	Shift + Pre Ch
EPG	EPG	-/-- / GUIDE	Guide
SLEEP	Sleep	PROG / SLEEP	Sleep
SEARCH MODE	Search Mode	SHIFT + TIMER / AV	Shift + AV
	Ball / Angle	SETTINGS / OPT	Options
DISPLAY	Display	SHIFT + DISPLAY / INFO	Shift + Info
PRESETS	Presets	SEARCH / TV/R	TV/R

Original	Sustituto