Original		Sustituto	
POWER	Power	POWER	Power
MUTE	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
FAV	FAV	FAV PRE-CH	Pre Ch
SUB-T	SUB-T	AD SUBT	Subt
OPTION	Option	SETTINGS OPT	Options
SETUP	Setup	TOP MENU MENU	Menu
	Up		Up

Original		Sustituto	
	Right		Right
	Down		Down
	Left		Left
OK	OK	OK	Ok
EXIT	Exit	CLEAR EXIT	Exit
HOME	Home	HOME SMART	Smart
	<<		<<
	>>		>>
	Play / Pause	PLAY MODE	Play
	Play / Pause		Pause
	Stop		Stop
	TV System	APP MEDIA	Media
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
	Edit	E-MANUAL D.MENU	D. Menu
AUDIO	Audio	SOUND DUAL	Dual
INFO	Info	DISPLAY INFO	Info

Original	Sustituto	Original	Sustituto
I << / P +	Ch +		
I << / P +	I <<		
>>I / P -	Ch -		
>>I / P -	>>I		
Repeat	Text		
Got o	Gui de		
Zoom	Ej ect		