Original		Sustituto	
POWER	Power		Power
OPEN/CLOSE	Open/Close	ZOOM	Eject
SETUP	Setup	SETTINGS OPT	Options
VIDEO ON/OFF	Video On/Off	SEARCH TV/R	TV/R
DIMMER	Dimmer	HOME SMART	Smart
MARKER	Marker	APP MEDIA	Media
PROGRAM	Program	PROG SLEEP	Sleep
SEARCH	Search	SHIFT + SEARCH TV/R	Shift + TV/R
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
PAUSE	Pause		Pause
PREV.	I<< Prev		I<<
NEXT	>>I Next		>>I
REW	<< Rew		<<
FF	>>FF		>>
MENU	Menu	TOP MENU MENU	Menu
	Up		Up

Original		Sustituto	
	Down		Down
	Left		Left
	Right		Right
ENTER	Enter	OK	Ok
AUDIO	Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
ANGLE	Angle	PICTURE FORMAT	Format
TOP MENU	Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
RETURN	Return	RETURN BACK	Back
DISPLAY	Display	DISPLAY INFO	Info
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7

Original		Sustituto		Original	Sustituto
8	8	8	8		
9	9	9	9		
CLEAR	Clear	CLEAR EXIT	Exit		
0	0	0	0		
+10	+10	-/-- GUIDE	Guide		
A-B	A-B	SHIFT + PLAY MODE	Shift + Play		
REPEAT	Repeat	REPEAT TEXT	Text		
S. MODE	S. Mode	DISC NAV LIST	List		
CONDITION	Condition	SHIFT + AD SUBT	Shift + Subt		
VIDEO ADJ.	Video Adj.	SHIFT + PICTURE FORMAT	Shift + Format		
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject		
RANDOM	Random	E-MANUAL D.MENU	D. Menu		
PAGE	Page	TIMER AV	AV		